



D Addario Auto Trim Tuning Machines Instructions

[Home](#) » [D ADDARIO](#) » D Addario Auto Trim Tuning Machines Instructions 

D Addario Auto Trim Tuning Machines



Contents

- [1 AUTO-TRIM LOCKING TUNING MACHINES](#)
- [2 Instructions](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

AUTO-TRIM LOCKING TUNING MACHINES

The Auto-Trim Tuners are precision locking tuners automatically trim the excess string ends, making string changes fast and easy by eliminating the need for clippers and multiple wraps. the 18:1 gear ratio construction ensures smooth, exact tuning while preventing backlash and slippage even during the hardest playing. please follow the instructions below when changing strings to ensure the proper performance from these tuners.

Instructions

1. Feed string through studded side of tuner



2. Pull string taut and tighten tuner locking knob



3. Tune to pitch allowing tuner to trim excess string



Documents / Resources

3 Steps AUTO-TRIM LOCKING TUNING MACHINES The Auto Trim Tuning Machines are precision locking tuners that are built from the highest quality materials, featuring a unique design that allows for easy installation and removal. The Auto Trim Tuning Machines are built from the highest quality materials, featuring a unique design that allows for easy installation and removal. The Auto Trim Tuning Machines are built from the highest quality materials, featuring a unique design that allows for easy installation and removal. 1. Insert the string into the tuning machine and pull it through the hole. 2. Pull the string back and forth to seat it properly. 3. Turn the string counter-clockwise to lock it in place.	D Addario Auto Trim Tuning Machines [pdf] Instructions Auto Trim Tuning Machines, Auto Trim, Tuning Machines, Machines
--	---