



D-Link DAP-1325 Wifi Range Extender Installation Guide

[Home](#) » [D-Link](#) » D-Link DAP-1325 Wifi Range Extender Installation Guide 

D-Link[®] QUICK INSTALLATION GUIDE DAP-1325

Contents

- [1 OPTION 1 QRS MOBILE APP SETUP](#)
- [2 OPTION 2 WEB BROWSER SETUP](#)
- [3 FREQUENTLY ASKED QUESTIONS](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)


OPTION 1 QRS MOBILE APP SETUP

1. Scan the QR code below to download the QRS Mobile app from the App Store or from Google Play and launch it.

Note: Please check the app store for device requirements and compatibility. Not all D-Link products are supported by the QRS Mobile app.




2. Once the app is installed, you may now configure your device. Connect to the device wirelessly by going to the wireless utility on your device. Scan for the wireless network name as listed on the supplied Wi-Fi Configuration Card. Select the network and then enter the password.



3. Once you connect to the device, tap on the QRS Mobile icon from your mobile device, then tap Start to continue. Follow the on-screen instructions to complete the setup.


OPTION 2 WEB BROWSER SETUP

1. Plug the extender into a power source close to your router.



2. Wait for the Power LED of the extender to start blinking amber.

Note: Please refer to the User Manual for device-specific LED behavior.



3. Connect your computer to the Wi-Fi name and password printed on the Quick Installation Card, or on the device label of the device.



4. Type [http://dlinkap.local./](http://dlinkap.local/) into the address bar of a web browser. Follow the on-screen instructions to complete the setup.




ENJOY!

You're all good to go! Connect devices to your network using the Wi-Fi Name (SSID) and password that you created during the setup process.


PLACEMENT



Note: Please refer to the User Manual for device-specific LED behavior. One amber bar indicates a weak signal. Move your extender closer to your router to improve signal quality. Make sure that your extender is placed in an open environment.



Place the extender in the range of your router. Check the LED indicator on your extender to ensure a proper connection. Green bars indicate a strong signal.



FREQUENTLY ASKED QUESTIONS

Why can't I connect to my wireless router or does my wireless connection drops?

Verify that your extender is within range of your router. Try plugging it into a location closer to the router and verify the Signal LED is solid green. Note that when extending a wireless signal from a router or access point, devices connected to the extender will not get the same speed/throughput as when connected directly to the router.

How do I change the wireless settings on my extender?

To change your Wi-Fi Network Name (SSID) and modify the security (Wi-Fi password), access the wireless settings via:



- The Wi-Fi section in the settings menu of the D-Link Wi-Fi app or
- Access the web-based configuration utility > Settings > Extender.

What if I forgot my extender's Admin password or want to reset my extender?

If you forgot your Admin password or want to reset your extender back to the factory default settings, press and hold the reset button on the bottom of the extender using a paper clip and release after a minimum of 10 seconds. The Status LED will turn red.

For technical support, product documentation, and other information, please visit our website.

<https://eu.dlink.com/support>

 	D-Link DAP-1325 Wifi Range Extender [pdf] Installation Guide DAP-1325, Wifi Range Extender, DAP-1325 Wifi Range Extender
--	---

References

- [D For Home | D-Link](#)
- [D For Home | D-Link](#)