



D-LINK DAP-2680 Wireless Access Point User Guide

[Home](#) » [D-Link](#) » D-LINK DAP-2680 Wireless Access Point User Guide 







D-LINK DAP-2680 Wireless Access Point User Guide



Contents


- [1 Connection](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

Connection





1.



SSID: dlink



DAP-2680



DHCP SERVER

2.

http:// dap2680.local

User Name: admin

Password: admin



SSID: dlink




DAP-2680





DHCP SERVER

3.



OR






OR



1.

2.



<https://www.nuclias.com>



<https://download.nuclias.com>




<https://www.dlink.com/support>



<https://www.dlink.com/warranty>



Documents / Resources



[D-LINK DAP-2680 Wireless Access Point](#) [pdf] User Guide
DAP-2680 Wireless Access Point, DAP-2680, Wireless Access Point, Access Point, Point

References

- [Nuclias connect Home](#)
- [D-Link Support](#)
- [nuclias.com](#)
- [User Manual](#)

Manuals+ Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.