



D-Link DEM-QX10Q-LR4 40GBase-LR4 Single-Mode QSFP+ Transceiver Installation Guide

[Home](#) » [D-Link](#) » **D-Link DEM-QX10Q-LR4 40GBase-LR4 Single-Mode QSFP+ Transceiver Installation Guide**

D-Link DEM-QX10Q-LR4 40GBase-LR4 Single-Mode QSFP+ Transceiver




Contents

- 1 Connecting the transceiver
- 2 Documents / Resources
 - 2.1 References
- 3 Related Posts

Connecting the transceiver

Plug the DEM-QX10Q-LR4 transceiver into the QSFP+ port of your switch. Connect a fiber cable to the DEM-QX10Q-LR4 transceiver in order to connect your switch to fiber media.



The DEM-QX10Q-LR4 transceiver is hot pluggable. You can connect the transceiver while the system is powered on without causing any issues, and easily plug or unplug the transceiver without interrupting the network operation.

072-2575555

support@dlink.co.il



Documents / Resources

	D-Link DEM-QX10Q-LR4 40GBase-LR4 Single-Mode QSFP+ Transceiver [pdf] Installation Guide DEM-QX10Q-LR4, 40GBase-LR4 Single-Mode QSFP Transceiver, DEM-QX10Q-LR4 40GBase-LR4 Single-Mode QSFP Transceiver
---	---

References

- almaty@dlink.ru
- info@dlink.am
- info@dlink.ee

- [!\[\]\(7e19807c61da14f515588e95cd49886c_img.jpg\) info@dlink.it](mailto:info@dlink.it)
- [!\[\]\(8ff9e60a4b0560d7ec99179ef4779d9e_img.jpg\) info@dlink.md](mailto:info@dlink.md)
- [!\[\]\(ab9b69bf5753a01c76b30af859454360_img.jpg\) mail@dlink.ru](mailto:mail@dlink.ru)
- [!\[\]\(c5af66b13c724ca428497900cdbbc9b3_img.jpg\) support@dlink.by](mailto:support@dlink.by)
- [!\[\]\(1fde827780c8f912fd3ae9174d52d155_img.jpg\) support@dlink.co.il](mailto:support@dlink.co.il)
- [!\[\]\(49ab9fdb6ddb6816bcb8ccc012d5cebd_img.jpg\) ua@dlink.ua](mailto:ua@dlink.ua)
- [!\[\]\(a10cf212d457430b842f8ac59c63db70_img.jpg\) D-Link Главная](#)

Manuals+