

D-Link DSL-G225 Wireless N300 ADSL2+/VDSL2 Modem Router



D-Link DSL-G225 Wireless N300 ADSL2+/VDSL2 Modem Router Installation Guide

[Home](#) » [D-Link](#) » D-Link DSL-G225 Wireless N300 ADSL2+/VDSL2 Modem Router Installation Guide 

Contents

- [1 D-Link DSL-G225 Wireless N300 ADSL2+/VDSL2 Modem Router](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
 - [3.1 Product Setup](#)
- [4 Troubleshooting](#)
- [5 Frequently Asked Questions \(FAQ\)](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



D-Link DSL-G225 Wireless N300 ADSL2+/VDSL2 Modem Router



Product Information

Specifications

- **Model:** DSL-G225
- **Wireless Standard:** N300
- **Modem Type:** ADSL2+/VDSL2
- **Contents of Packaging:**
 - Wireless N300 ADSL2+/VDSL2 Modem Router DSL-G225
 - Power Adapter
 - Ethernet Cable (CAT5 UTP)
 - RJ-11 Phone Cable
 - ADSL/VDSL Splitter

CONTENTS OF PACKAGING

- WIRELESS N300 ADSL2+/VDSL2 MODEM ROUTER
 - DSL-G225
- POWER ADAPTER
 - ADAPTER
- ETHERNET CABLE (CAT5 UTP)
 - CONNECT THE ROUTER TO YOUR PC DURING SET-UP
- RJ-11 PHONE CABLE
- ADSL/VDSL SPLITTER



If any of these items are missing from your packaging contact your reseller

Product Usage Instructions

Product Setup

Before You Start


Make sure you have your Internet Provider Account Details ready before proceeding. Internet Provider Account Details – If you are using an Australian or New Zealand ADSL or VDSL connection, you will need your user name and password. If you do not have this information, contact your Internet Service Provider. If you are using an Australian or New Zealand NBN or UFB connection, you may also need a user name and password. Please check before proceeding. Do not proceed until you have this information.

Connect Your Modem Router – ADSL/VDSL


1. Connect the supplied Splitter/Filter to your telephone outlet.
2. Plug one end of the supplied RJ-11 phone cable into the DSL port of the Splitter/Filter and the other end into the DSL port of the Router.
3. Connect one end of the supplied Ethernet cable to an Ethernet port on the Router and the other end to the Ethernet port on your computer.
4. Plug the power adapter into the back of the Router and power it on.

Setup Wizard – ADSL/VDSL


1. Open a web browser (e.g., Internet Explorer, Chrome, Firefox, or Safari) and enter '192.168.1.1' into the address bar (<http://192.168.1.1>).
2. When prompted, enter 'admin' into both the username and password fields and click 'Login'.



3. Click on 'Setup Wizard' to start configuring your Router.



4. Click through until you reach 'Setup Internet Connection' (Step 3). Select your Country and ISP from the drop down box. Then enter the Username and Password as supplied by your ISP.



5. Continue through the steps. You have the option to change Wi-Fi settings and to change account passwords.

When you reach Step 5, click 'Apply' to save your settings.

6. After the Router saves your settings, you should be online and able to share this Internet connection with multiple wired and wireless devices.

Troubleshooting

Set-Up and Configuration Problems

1. HOW DO I CONFIGURE MY DSL-G225 ROUTER, OR CHECK MY WIRELESS NETWORK NAME (SSID) AND WIRELESS ENCRYPTION KEY?

1. Connect your PC to the router using an Ethernet cable.
2. Open a web browser and enter the address <http://192.168.1.1>
3. The default username is 'admin'. The default password is 'admin'.
4. If you have changed the password and can not remember it, you will need to reset the router to set the password back to 'admin'.

2. HOW DO I RESET MY DSL-G225 ROUTER TO FACTORY DEFAULT SETTINGS?

1. Ensure the router is powered on.
2. Press and hold the reset button on the back of the device for 10 seconds.

Note: Resetting the router to factory default will erase the current configuration settings. To reconfigure your settings, log into the router as outlined in question 1, then run the Setup Wizard.

3. HOW DO I ADD A NEW WIRELESS CLIENT OR PC IF I HAVE FORGOTTEN MY WIRELESS NETWORK NAME (SSID) OR WIRELESS ENCRYPTION KEY?

1. Every PC that needs to connect to the router wirelessly, you will need to ensure you use the correct Wireless Network Name (SSID) and encryption key.
2. Use the web based user interface (as described in question 1 above) to check or choose your wireless settings.
3. Make sure you write down these settings so that you can enter them into each wirelessly connected PC. You will find a dedicated area on the back of this document to record this important information for future use.

4. WHY CAN I NOT GET AN INTERNET CONNECTION?

1. Please contact your ISP to make sure the service has been enabled/connected by your ISP and that your ISP username and password is correct.

WIRELESS NETWORK REMINDER

Wireless Network Name (SSID)

Wireless Network Password

Frequently Asked Questions (FAQ)

Q: What do I do if my Internet connection is slow?


A: Make sure your devices are within range of the router, minimize interference, and consider upgrading your

internet plan.

Q: Can I connect a printer to this modem router?

A: Yes, you can connect a printer to one of the Ethernet ports on the router for network printing.

Documents / Resources

	<p>D-Link DSL-G225 Wireless N300 ADSL2+/VDSL2 Modem Router [pdf] Installation Guide DSL-G225 Wireless N300 ADSL2 VDSL2 Modem Router, DSL-G225, Wireless N300 ADSL2 VD SL2 Modem Router, N300 ADSL2 VDSL2 Modem Router, ADSL2 VDSL2 Modem Router, VDSL 2 Modem Router, Modem Router, Router</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.