



dahua 8018 Universal Mounting Bracket User Manual

[Home](#) » [Dahua](#) » dahua 8018 Universal Mounting Bracket User Manual 

Contents

- [1 dahua 8018 Universal Mounting Bracket](#)
- [2 Product Information](#)
- [3 DIMENSION](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)



dahua 8018 Universal Mounting Bracket



Product Information


Model	8018
Material	Aluminum
Dimension (WxWxD)	4.53" x 4.53" x 3.92"
Weight	0.5 kg (1.10 lbs)
Loading Wall	10 kg (22.05 lbs)
Colour	White
Operating Temperature	0%-90% RH
Humidity Applicable Model	Universal

Product Usage Instructions

1. Ensure that the surface where you plan to mount the bracket is clean and dry.
2. Take the Universal Mounting Bracket out of the packaging.
3. Position the bracket against the desired wall or surface.
4. Mark the areas where you will need to drill holes for the bracket.
5. Using an appropriate drill bit, carefully drill the holes at the marked positions.
6. Insert suitable wall plugs into the drilled holes.
7. Align the bracket holes with the wall plugs and screw in the provided screws.
8. Tighten the screws securely, ensuring that the bracket is firmly attached to the wall or surface.
9. Verify that the bracket is level and straight.
10. Now you can load your desired object onto the bracket, ensuring it does not exceed the loading capacity of 10 kg (22.05 lbs).

DIMENSION

•



aesthetic design.

- Casing support.
- Support three-axis rotation for housing installation.

Documents / Resources



dahua 8018 Universal Mounting Bracket [pdf] User Manual

8018 Universal Mounting Bracket, 8018, Universal Mounting Bracket, Mounting Bracket, Bracket

References

- 🔗 [Free Online Translator - Preserves your document's layout \(PDF, Word, Excel, PowerPoint, OpenOffice, text\)](#)
- 🔗 [Free Online Translator - Preserves your document's layout \(PDF, Word, Excel, PowerPoint, OpenOffice, text\)](#)