



dahua IPC-B2B20-40-ZS IP Camera Instructions

[Home](#) » [Dahua](#) » dahua IPC-B2B20-40-ZS IP Camera Instructions 



Contents

- [1 dahua IPC-B2B20-40-ZS IP Camera](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Shape](#)
- [5 IP Camera](#)
- [6 CVI Camera](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)

dahua IPC-B2B20-40-ZS IP Camera



Product Information

- **Product Name:** IP Camera
- **Other Available Products:** Shape Camera, Junction Box, CVICamera, Pole/Corner Mount
- **Recommended Accessories:** PFA135, PFA130-E, PFA152-E, PFA151, PFA122, PFA13G
- **Manufacturer Website:** www.kdelectronics.ie

Product Usage Instructions

1. Unbox the IP Camera along with any additional accessories purchased.
2. If required, refer to the user manual of the specific accessory (e.g., Shape Camera, Junction Box, CVI Camera, Pole/Corner Mount) for installation instructions.
3. Choose an appropriate location for mounting the IP Camera.
4. If using a Shape Camera, follow the installation instructions provided in its user manual.
5. If using a Junction Box, refer to the user manual for proper installation and connection of the IP Camera.
6. If using a CVI Camera, follow the installation instructions provided in its user manual.
7. For mounting on a pole or corner, use the Pole/Corner Mount accessory and consult its user manual for installation instructions.
8. Ensure all connections are secure and properly aligned.
9. Connect the IP Camera to a power source as per the user manual instructions.
10. Configure the IP Camera settings according to your requirements. Refer to the IP Camera user manual for detailed instructions on how to do this.
11. Once installation and configuration are complete, you can start using the IP Camera for surveillance or any other intended purpose.

Shape



IP Camera


- IPC-HFW2120/2220/2320R-ZS/VFS
- IPC-HFW2120/2220/2221/2320/2231/2421R-ZS/VFS-IRE6
- IPC-HFW4120D(-AS)
- IPC-HFW4120B(-AS)
- IPC-B2B20/40-ZS
- IPC-B2B20-L-ZS
- IPC-HFW5442/5541/5241T-S
- IPC-HFW5442/5541/5241T-SE
- IPC-HFW2831/2531/2431/2231T-AS-S2
- IPC-HFW4239/4431/4631/4831/5442/5541/5241T-ASE
- IPC-HFW5842T-ASE-S2
- IPC-HFW5241/5442T-ASE-NI
- IPC-HFW5242T-ASE-MF
- IPC-HFW4431/4231T-S-S4
- IPC-HFW5541/5241T-AS-PV
- IPC-HFW5449T-ASE-LED
- IPC-HFW5241/5442T-AS-LED
- IPC-HFW2531/2431/2231T-ZS/VFS
- IPC-HFW2831/2531/2431/2231T-ZS-S2
- IPC-HFW3841/3241/3441/3541/T-ZS
- IPC-HFW3541/3841/3241/3441T-ZAS
- IPC-HFW2831/2531/2431/2231T-ZAS-S2
- IPC-HFW3549/3449/3249/3849T1-AS-PV
- IPC-HFW5849T1-ASE-LED

- IPC-HFW5449T1-ASE-D2
- IPC-HFW5449T1-ZE-LED
- IPC-HFW3449/3849/3549T1-AS-PV-S3

CVI Camera

- HAC-ME1809/1509TH-A-PV-POC
- HAC-ME1809/1509TH-A-PV
- HAC-ME1800/1509/TH-PV
- HAC-HFW1500R-Z-IRE-A-DP
- HAC-HFW1200R-Z-IRE6-A-POC
- HAC-HFW1231TM-I8-A
- HAC-HFW1231R-Z-A
- HAC-B3A51/21-Z
- HAC-HFW1231R-Z-A-DP
- HAC-HFW1100/1200/1220/1400R-VF
- HAC-HFW1100/1200/1220/1400R-VF-IRE6
- HAC-HFW2221/2231/2401/1200/1230/1400/1500R-Z-IRE6
- HAC-HFW2221/2231/2401R-Z-IRE6-DP
- HAC-HFW2231R-Z-POC
- HAC-HFW2231/1230/1400/1500R-Z-IRE6-POC
- HAC-HFW2221R-Z-IRE6-0722
- HAC-HFW1500R-Z-IRE6-A
- HAC-HFW1200/1500R-Z-IRE6(-A)
- HAC-HFW1500R-Z-IRE6-A-DP
- HAC-HFW2401/2221/1100/1200/1220/1400/2231/1230/1500D
- HAC-HFW1200/1220/1400/2231B
- HAC-B4A21/41/51-VF
- HAC-HFW1200/1220TH
- HAC-HFW1200TH-A
- HAC-HFW1801/1500/1400/1230/1220/1200/1800TH-I8
- HAC-HFW1801/1500/1400/1230/1220/1200/1800TH-I4
- HAC-HFW1231TM-I8-A
- HAC-HFW1200TH-I8-A-POC
- HAC-HFW2802/2601/2241/2501/2402T-Z-A
- HAC-HFW2802/2601/2241/2501/2402T-Z-A-DP
- HAC-HFW2241T-Z-POC
- HAC-HFW2241T-Z-A-VP-0622
- HAC-HFW2501/2241TU-Z-A
- HAC-HFW2501/2241TU-Z-A-DP
- HAC-HFW2241TU-Z-A-POC
- HAC-HFW2802T-A-I8
- HAC-HFW2241/2249/2501/2402T-I8-A

- HAC-HFW2249T-I8-A-LED
- HAC-HFW1509T-A-LED-POC
- HAC-HDW1509T-A-LED-POC
- HAC-HFW2249T-A-LED
- HAC-HFW1800T(-A)
- HAC-HFW1239/1509TU-Z-A-LED-DP
- HAC-HFW1239/1509/2249TU-Z-A-LED
- HAC-HFW2501/2241TU-A
- HAC-HFW2241TU-A-POC
- HAC-HFW1239/1509MH-A-LED
- HAC-HFW1239MH(-A)-LED



Recommended: www.kdelectronics.ie.

Documents / Resources

	dahua IPC-B2B20-40-ZS IP Camera [pdf] Instructions IPC-HFW2120-2220-2320R-ZS-VFS, IPC-HFW2120-2220-2221-2320-2231-2421R-ZS-VFS-IR E6, IPC-HFW4120D -AS, IPC-HFW4120B -AS, IPC-B2B20-40-ZS, IPC-B2B20-L-ZS, HAC-ME1809-1509TH-A-PV-POC, HAC-ME1809-1509TH-A-PV, HAC-ME1800-1509-TH-PV, HAC-HFW1500R-Z-IRE-A-DP, HAC-HFW1200R-Z-IRE6-A-POC, IPC-B2B20-40-ZS IP Camera, IPC-B2B20-40-ZS, IP Camera, Camera
--	--

References

- **[KD Electronics Ireland - Trade Supplier of CCTV, Security Systems, Audio Visual and Networking solutions - CCTV, TV, Audio & Networking Distributor Cork](#)**