



dahua IPC-HFW1230S-0360B-S5 Bullet Network Camera User Guide

[Home](#) » [Dahua](#) » dahua IPC-HFW1230S-0360B-S5 Bullet Network Camera User Guide 

Contents

- [1 dahua IPC-HFW1230S-0360B-S5 Bullet Network](#)
- [2 Bullet Network Camera](#)
- [3 Foreword](#)
- [4 Important Safeguards and Warnings](#)
- [5 Introduction](#)
- [6 Network Configuration](#)
- [7 Installation](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)



dahua IPC-HFW1230S-0360B-S5 Bullet Network



Bullet Network Camera

Quick Start Guide

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.

Version: V1.0.2

Foreword

This manual provides information on the installation and operation of the network camera. It is important to read the manual carefully before using the device and keep it safe for future reference.

Safety Instructions

The manual contains signal words that indicate the potential hazard level.

Signal Words	Meaning
Danger	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
Warning	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
Caution	Indicates a potential risk which, if not avoided, may result in property damage, data loss, reductions in performance, or unpredictable result.
Note	Provides additional information as a supplement to the text.

Revision History

The manual may be updated according to the latest laws and regulations. For the latest information, refer to the paper User Manual, use the CD-ROM, scan the QR code, or visit the official website. The manual is for reference only, and slight differences may be found between the electronic version and the paper version.

Version	Revision Content	Release Date
V1.0.2	Updated the information of installing the camera. Updated Important Safeguards and Warnings.	August 2022
V1.0.1	Updated Important Safeguards and Warnings.	April 2021
V1.0.0	First release.	March 2018

Privacy Protection Notice

If you are using the device as a data controller, you must comply with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures including but not limited to providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

Important Safeguards and Warnings

This section covers proper handling of the device, hazard prevention, and prevention of property damage. Please read carefully before using the device and follow the guidelines.

Product Usage Instructions

1. Mount the camera in a suitable location.
2. Connect the camera to a power source and network via Ethernet or Wi-Fi.
3. Configure the camera settings using the provided software or web interface.
4. View the camera footage through the software or web interface.
5. For more detailed instructions, refer to the User Manual or contact customer service.





Foreword

General

This manual introduces the installation and operations of network camera. Read carefully before using the device, and keep the manual safe for future reference.

Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, may result in property damage, data loss, reductions in performance, or unpredictable result.
 NOTE	Provides additional information as a supplement to the text.

Revision History

Version	Revision Content	Release Date
V1.0.2	Updated the information of installing the camera.	August 2022
V1.0.1	Updated “Important Safeguards and Warnings.”	April 2021
V1.0.0	First release.	March 2018

Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating of the product in ways that are not in compliance with the manual.
- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper User Manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All the designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be deviations in the description of the technical data, functions and operations, or errors in the print. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguards and Warnings

This section introduces content covering the proper handling of the device, hazard prevention, and prevention of property damage. Read carefully before using the device, comply with the guidelines when using it.

Transportation Requirements

- Transport the device under allowed humidity and temperature conditions.
- Pack the device with packaging provided by its manufacturer or packaging of the same quality before transporting it.

- Do not place heavy stress on the device, violently vibrate or immerse it in liquid during transportation.

Storage Requirements

- Store the device under allowed humidity and temperature conditions.
- Do not place the device in a humid, dusty, extremely hot or cold site that has strong electromagnetic radiation or unstable illumination.
- Do not place heavy stress on the device, violently vibrate or immerse it in liquid during storage.

Installation Requirements

- Strictly comply with the local electrical safety code and standards, and check whether the power supply is correct before operating the device.
- Please follow the electrical requirements to power the device.
 - When selecting the power adapter, the power supply must conform to the requirements of ES1 in IEC 62368-1 standard and be no higher than PS2. Please note that the power supply requirements are subject to the device label.
 - We recommend using the power adapter provided with the device.
- Do not connect the device to two or more kinds of power supplies, unless otherwise specified, to avoid damage to the device.
- The device must be installed in a location that only professionals can access, to avoid the risk of non-professionals becoming injured from accessing the area while the device is working. Professionals must have full knowledge of the safeguards and warnings of using the device.
- Do not place heavy stress on the device, violently vibrate or immerse it in liquid during installation.
- An emergency disconnect device must be installed during installation and wiring at a readily accessible location for emergency power cut-off.
- We recommend you use the device with a lightning protection device for stronger protection against lightning. For outdoor scenarios, strictly comply with the lightning protection regulations.
- Ground the function earthing portion of the device to improve its reliability (certain models are not equipped with earthing holes). The device is a class I electrical appliance. Make sure that the power supply of the device is connected to a power socket with protective earthing.
- The dome cover is an optical component. Do not directly touch or wipe the surface of the cover during installation.

Operation Requirements

- The cover must not be opened while the device is powered on.
- Do not touch the heat dissipation component of the device to avoid the risk of getting burnt.
- Use the device under allowed humidity and temperature conditions.
- Do not aim the device at strong light sources (such as lamplight, and sunlight) when focusing it, to avoid reducing the lifespan of the CMOS sensor, and causing overbrightness and flickering.
- When using a laser beam device, avoid exposing the device surface to laser beam radiation.
- Prevent liquid from flowing into the device to avoid damage to its internal components.
- Protect indoor devices from rain and dampness to avoid electric shocks and fires breaking out.

- Do not block the ventilation opening near the device to avoid heat accumulation.
- Protect the line cord and wires from being walked on or squeezed particularly at plugs, power sockets, and the point where they exit from the device.
- Do not directly touch the photosensitive CMOS. Use an air blower to clean the dust or dirt on the lens.
- The dome cover is an optical component. Do not directly touch or wipe the surface of the cover when using it.
- There might be a risk of electrostatic discharge on the dome cover. Power off the device when installing the cover after the camera finishes adjustment. Do not directly touch the cover and make sure the cover is not exposed to other equipment or human bodies
- Strengthen the protection of the network, device data and personal information. All necessary safety measures to ensure the network security of the device must be taken, such as using strong passwords, regularly changing your password, updating firmware to the latest version, and isolating computer networks. For the IPC firmware of some previous versions, the ONVIF password will not be automatically synchronized after the main password of the system has been changed. You need to update the firmware or change the password manually.

Maintenance Requirements

- Strictly follow the instructions to disassemble the device. Non-professionals dismantling the device can result in it leaking water or producing poor quality images. For a device that is required to be disassembled before use, make sure the seal ring is flat and in the seal groove when putting the cover back on. When you find condensed water forming on the lens or the desiccant becomes green after you disassembled the device, contact after-sales service to replace the desiccant. Desiccants might not be provided depending on the actual model.
- Use the accessories suggested by the manufacturer. Installation and maintenance must be performed by qualified professionals.
- Do not directly touch the photosensitive CMOS. Use an air blower to clean the dust or dirt on the lens. When it is necessary to clean the device, slightly wet a soft cloth with alcohol, and gently wipe away the dirt.
- Clean the device body with a soft dry cloth. If there are any stubborn stains, clean them away with a soft cloth dipped in a neutral detergent, and then wipe the surface dry. Do not use volatile solvents such as ethyl alcohol, benzene, diluent, or abrasive detergents on the device to avoid damaging the coating and degrading the performance of the device.
- The dome cover is an optical component. When it is contaminated with dust, grease, or fingerprints, use degreasing cotton moistened with a little ether or a clean soft cloth dipped in water to gently wipe it clean. An air gun is useful for blowing dust away.
- It is normal for a camera made of stainless steel to develop rust on its surface after being used in a strong corrosive environment (such as the seaside, and chemical plants). Use an abrasive soft cloth moistened with a little acid solution (vinegar is recommended) to gently wipe it away. Afterwards, wipe it dry.

Introduction

Waterproof all the cable joints with insulating tape and waterproof tape to avoid water damage and prevent short circuits from occurring. For details, see the FAQ manual.




Table 1-1 Cable information

No.	Port Name	Function
1	Ethernet Port	Connects to network with network cable. Provides power to the device with PoE. Po E is available on select model.
2	Power Input	Inputs 12 VDC power. Please be sure to supply power as instructed in the Guide. Device abnormality or damage could occur if power is not supplied correctly.

Network Configuration

Device initialization and IP setting can be finished with the Config Tool or in web page. For more information, see the WEB operation manual.

- Device initialization is available on select models, and it is required at first use and after device is reset.
- Device initialization is available only when the IP addresses of the device (192.168.1.108 by default) and the PC stays on the same network segment.
- Carefully plan the network segment for the device.
- The following figures and pages are for reference only.

Initializing the Camera

Search for the device that needs to be initialized through ConfigTool.

- Double-click ConfigTool.exe to open the tool.
- Click Modify IP.
- Select the searching way, and then click OK.
- Select one or several cameras in uninitialized status, and then click Initialize. Select the devices to be initialized, and then click Initialize.

If you do not provide the email address for password reset, you can reset the password only through XML file.

- Select Auto-check for updates as needed, and then click OK to initialize the device. If initialization failed, click to see more information.
- Click Finish.

Changing the Device IP Address

- You can change the IP address of one or more devices at a time. This section is based on changing IP addresses in batches.
- Changing IP addresses in batches is available only when the corresponding devices have the same login password.
- Search for the device whose IP address needs to be changed through ConfigTool.
 - Double-click ConfigTool.exe to open the tool.
 - Click Modify IP.
 - Select the searching way, enter the username and password, and then click OK.
- The username is admin, and the password is the one you set while initializing the device.
- Select the devices whose IP addresses need to be changed, and then click Modify IP. Configure IP address.
 - Static mode: When you select Static, you need to enter Start IP, Subnet Mask, and Gateway. The IP addresses of the devices will be modified successively starting from the first IP entered.
 - DHCP mode: If the DHCP server is available in the network, when you select DHCP, the IP address of devices will be automatically obtained through the DHCP server.

The same IP address will be set for multiple devices if you select the Same IP checkbox.
- Click OK.

Logging in to the Web Page


- Open the IE browser, enter the IP address of the device in the address bar, and then press the Enter key. If the setup wizard opens, follow the on-screen instructions to complete it.

- Enter the username and password in the login box, and then click Login. (Optional) For first-time login, click [Click Here to Download Plugin](#), and then install the plugin as instructed.
- The home page opens when installation is complete.


Installation

Packing List

- Tools required for installation, such as the electric drill, are not included in the package.
- The operation manual and information on the tools are on the disk or the QR code.




Dimensions




Installing the Camera

Installation Methods




(Optional) Installing the SD Card

- Press the reset button for 10 seconds to reset the device.
- For wireless devices, press the reset button for 4-5 seconds to enable WPS.



LED Indicator Status	Device Status
Red light on	Booting Device malfunction
Green light flashing	Waiting for network
Green light on	Operating properly
Green light rapid flashing	Waiting for WPS connection
Red light flashing	Network connection failed
Red light rapid flashing	SD card malfunction
Light off	Powered off Rebooting after reset
Green and Red light flashing alternately	Firmware updating


(Optional) Installing the Antenna




Attaching the Camera

Make sure the mounting surface is strong enough to hold at least three times of the device weight.

Cable going through the mounting surface




Cable going through the side cable tray



Installing Waterproof Connector


This part is only needed when a waterproof connector comes with the device and the device is used outdoors.

Install waterproof connector



Adjusting the Lens Angle

Adjust the lens angle



ENABLING A SAFER SOCIETY AND SMARTER LIVING
ZHEJIANG DA HUA VISION TECHNOLOGY CO., LTD.

Address: No.1199 Bin'an Road, Binjiang District, Hangzhou, P.R. China

Website: www.dahuasecurity.com



Postcode: 310053

Email: overs.eas@dahuatech.com

Fax: +86-571-87688815

Tel: +86-571-87688883

Documents / Resources

 <small>Bullet Network Camera Quick Start Guide</small>  <small>DAHUANG DAHUA TECHNOLOGY CO., LTD. 70102</small>	<p>dahua IPC-HFW1230S-0360B-S5 Bullet Network Camera [pdf] User Guide</p> <p>IPC-HFW1230S-0360B-S5 Bullet Network Camera, IPC-HFW1230S-0360B-S5, Bullet Network Camera, Network Camera, Camera</p>
---	--