



# Danfoss 013G1246 Aero RA Click Remote Sensor Installation Guide

[Home](#) » [Danfoss](#) » Danfoss 013G1246 Aero RA Click Remote Sensor Installation Guide 

## Contents

- [1 Danfoss 013G1246 Aero RA Click Remote Sensor](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Installation](#)
- [5 BIV Installation](#)
- [6 Temperature Limitation](#)
- [7 Theft protection](#)
- [8 Documents / Resources](#)



**Danfoss 013G1246 Aero RA Click Remote Sensor**



## Product Information



This user manual is for the installation and usage of the thermostatic sensors series. The product code number for the sensors is 013G1246 or 013G1236. The manual provides instructions on how to install and use the sensors.

## Product Usage Instructions


1. Installation Guide: Follow the installation guide provided in the manual to correctly install the thermostatic sensors.
2. Click: There are multiple instances where it says “click” in the manual. Please refer to the corresponding steps or diagrams to understand the specific actions you need to take.
3. MAX Setting: To set the maximum temperature, enter the value “4” as indicated in the example (e.g., MAX = 4).
4. MIN Setting: To set the minimum temperature, enter the value “2” as indicated in the example (e.g., MIN = 2).
5. Blind Mark: There is a blind mark or marking mentioned in the manual. Please refer to the corresponding section or diagram to understand its significance or usage.


Please note that the above instructions are based on the provided text-extract from the user manual. For more detailed information and specific usage instructions, please refer to the complete user manual provided with your product.

## Installation




## BIV Installation






## Uninstall




## Remote sensor




## Temperature Limitation

1.




2.




3.


e.g.  
**MAX = 4**




4.




5.



1.




2.




3.

e.g.  
MIN = 2




4.



5.


MIN = 2






	Code no.
	013G1246
	013G1236

## Theft protection




## Theft protection (Removal)





	Code no.
	<b>013G5245</b>
	<b>013G1236</b>

#### Blind mark




#### Danfoss A/S

- Climate Solutions
- [danfoss.com](https://danfoss.com)
- +45 7488 2222

anginrates intons but seminise et in water ael tane in iting alication sly oint desia wria, disman be considered aromather techsial dating duct to anuals, eaters, reserves the right to ate inspotatiswiroue notice. This. pis to

products ordered but not diet ere provided that catalienators can be made wind thanges to form, fit or All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

## Documents / Resources

	<p><a href="#">Danfoss 013G1246 Aero RA Click Remote Sensor</a> [pdf] Installation Guide</p> <p>013G1246, 013G1236, 013G5245, 013G1246 Aero RA Click Remote Sensor, Aero RA Click Remote Sensor, RA Click Remote Sensor, Click Remote Sensor, Remote Sensor, Sensor</p>
---	---