



Danfoss 013G1246 Aero RA Click Thermostatic Sensors Instruction Manual

[Home](#) » [Danfoss](#) » Danfoss 013G1246 Aero RA Click Thermostatic Sensors Instruction Manual



Contents


- [1 Danfoss 013G1246 Aero RA Click Thermostatic Sensors](#)
- [2 Installation](#)
- [3 BIV Installation](#)
- [4 Uninstall](#)
- [5 Temperature Limitation](#)
- [6 Temperature Limitation](#)
- [7 Theft protection](#)
- [8 Documents / Resources](#)




Danfoss 013G1246 Aero RA Click Thermostatic Sensors




Installation




BIV Installation



Uninstall




Temperature Limitation




Temperature Limitation

1.




2.




3.

e.g.
MIN = 2




4.




5.


MIN = 2




	Code no.
	013G1246
	013G1236

Theft protection






Theft protection (Removal)



	Code no.
	013G5245
	013G1236

Blind mark






Danfoss A/S

- Climate Solutions
- danfoss.com

+45 7488 2222 catinquestion, ptions advertisemite to and whether made ation in duct g, oralyational odine de via dovera, smanse considered ormate, techson ata ingrifauctmanuals extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product. All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

Documents / Resources

	Danfoss 013G1246 Aero RA Click Thermostatic Sensors [pdf] Instruction Manual 013G1246 Aero RA Click Thermostatic Sensors, 013G1246, Aero RA Click Thermostatic Sensors, Click Thermostatic Sensors, Thermostatic Sensors, Sensors
	Danfoss 013G1246 Aero RA Click Thermostatic Sensors [pdf] Installation Guide 013G1246 Aero RA Click Thermostatic Sensors, 013G1246, Aero RA Click Thermostatic Sensors, RA Click Thermostatic Sensors, Click Thermostatic Sensors, Thermostatic Sensors, Sensors
	Danfoss 013G1246 Aero RA Click Thermostatic Sensors [pdf] Installation Guide 013G1246 Aero RA Click Thermostatic Sensors, 013G1246, Aero RA Click Thermostatic Sensors, RA Click Thermostatic Sensors, Thermostatic Sensors, Sensors