

Danfoss 015G3392 Redia RA click Thermostatic Sensors **Installation Guide**

Home » Danfoss » Danfoss 015G3392 Redia RA click Thermostatic Sensors Installation Guide 🖺






ENGINEERING TOMORROW Installation Guide Danfoss Redia® RA click, RS / 015G3392 015G3382 Danfoss Redia® RA click, remote sensor thermostatic sensors series




Contents

- 1 Installation
- 2 BIV Installation
- 3 Uninstall
- 4 Remote sensor
- **5 Temperature Limitation**
- **6 Theft protection**
- 7 Blind mark
- 8 Documents /
- Resources
- 9 Related Posts


Installation




BIV Installation




Uninstall




Remote sensor




Temperature Limitation




Temperature Limitation



Theft protection




Theft protection (Removal)



Code no.
013G5245
013G1236

Blind mark



Danfoss AS Climate Solutions - danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product. All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

© Danfoss Climate Solutions I 2023.03 AN448534955949en-000101



Documents / Resources



<u>Danfoss 015G3392 Redia RA click Thermostatic Sensors</u> [pdf] Installation Guide 015G3382, 015G3392, 015G3392 Redia RA click Thermostatic Sensors, Redia RA click, Ther mostatic Sensors, Redia RA click Thermostatic Sensors

Manuals+,