

Danfoss 015G5348 React RA Built In Thermostatic Sensor Installation Guide

Home » Danfoss » Danfoss 015G5348 React RA Built In Thermostatic Sensor Installation Guide 🖺





TOMORROW
Danfoss Regus® RA nut +Valve /015G5317



Installation Guide
Danfoss Regus® RA nut
with RA-FN


Contents

- **1 VALVE Installation**
- **2 SENSOR Installation**
- 3 Documents /

Resources


4 Related Posts

VALVE Installation



	€	Min.[Nm]	Max.[Nm]
	DN10 3/8"	40	60
	DN15 1/2"	60	90
	DN20 3/4"	80	120

SENSOR Installation



Danfoss A/S


Climate Solutions « danfoss.com « +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, catalogues descriptions, advertisements, etc. and whether made available in writing, orall, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explict reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible capacity or any other technical data in product manuals errors in catalogues, brochures, Danfoss reserves the right to ater its products without notice. This also applies to products ordered but not delivered provided that such alterations videos and other material function of the product.

Al trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. Al rights reserved.

© Danfoss Climate Solutions | 2023.09 AN463940763622en-000101

Documents / Resources



Manuals+,