



Danfoss 015G5349 React RA Click with RA-N and RLV-S Installation Guide

[Home](#) » [Danfoss](#) » Danfoss 015G5349 React RA Click with RA-N and RLV-S Installation Guide 



Danfoss React™ RA Click Valve + Lockshield / 015G5348
015G5349




Installation Guide
Danfoss React™ RA Click
with RA-N & RLV-S


Contents

- [1 VALVE Installation](#)
- [2 LOCKSHEILD Installation](#)
- [3 Presetting table](#)
- [4 SENSOR Installation](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

VALVE Installation




LOCKSHEILD Installation



Presetting table

Code Number: Danfoss React™ 015G5348 015G5349	Δ_T			
	10K	15K	20K	
	~Watt			
	100	200	250	1
	250	400	550	2
	400	650	850	3
	650	950	1300	4
	900	1350	1800	5
	1150	1750	2300	6
	1350	2050	2750	7
	1900	2900	3850	N
	$\Delta_p=10\text{kPa}$			

SENSOR Installation



Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and

other material.

Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

Danfoss A/S
Climate Solutions


danfoss.com

+ +45 7488 2222

© Danfoss Climate Solutions
2023.09

AN463944878624en-000102

Documents / Resources

	<p>Danfoss 015G5349 React RA Click with RA-N and RLV-S [pdf] Installation Guide 015G5348, 015G5349, 015G5349 React RA Click with RA-N and RLV-S, 015G5349, React RA Click with RA-N and RLV-S, RA-N and RLV-S, RLV-S</p>
---	--

[Manuals+](#).