



Danfoss Aero RA Series Click Thermostatic Sensors Installation Guide

[Home](#) » [Danfoss](#) » Danfoss Aero RA Series Click Thermostatic Sensors Installation Guide 

Contents

- [1 Danfoss Aero RA Series Click Thermostatic Sensors](#)
- [2 Installation](#)
- [3 Uninstall](#)
- [4 Temperature Limitation](#)
- [5 Theft protection](#)
- [6 Blind mark](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



Danfoss Aero RA Series Click Thermostatic Sensors

**Product Information:**

The product is a device with a code number 013G1246 or 013G1236 or 013G5245 and a blind mark as indicated on the user manual. The maximum value for the device can be set to 4, and the minimum value can be set to 2.


Product Usage Instructions:

1. Start the installation process by following the steps outlined in the installation guide.
2. Once the device is installed, set the maximum value to 4 by inputting "MAX = 4" into the device.
3. Similarly, set the minimum value to 2 by inputting "MIN = 2" into the device.
4. The code number for the device can be found on the user manual, and it is recommended to keep this information for future reference.


Please note that any other specific instructions or details regarding the usage of the device may be available in the full user manual, which is not provided in this text-extract. For further assistance, please contact customer support.

Installation


1.




2.




3.



BIV Installation




Uninstall




Temperature Limitation

1.




2.




3.

e.g.
MAX = 4




4.

MAX




5.




MAX = 4

1.




2.




3.

e.g.
MIN = 2






4.







5.



MIN = 2




| | |
|---|-----------------|
| | Code no. |
|  | 013G1246 |
|  | 013G1236 |

Theft protection


| | |
|--|---|
| <p>1.</p>  | <p>2.</p>  |
| <p>3.</p>  | <p>4.</p>  |

| | |
|---|-----------------|
| | Code no. |
|  | 013G5245 |
|  | 013G1236 |

Theft protection (Removal)



Blind mark



© Danfoss Climate Solutions | 2023.03

Danfoss A/S

Climate Solutions

danfoss.com

+45 7488 2222

Any information, including, but not limited to information on the selection of the product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogs descriptions, advertisements, etc., and whether made available in writing, orally, electronically, online or via download, shall be considered informative and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogs, brochures, videos and other material.

Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to the form, fit, or function of the product. All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

Documents / Resources



[Danfoss Aero RA Series Click Thermostatic Sensors](#) [pdf] Installation Guide
013G1246, 013G1236, 013G5245, Aero RA Series Click Thermostatic Sensors, Aero RA Series, Click Thermostatic Sensors, Thermostatic Sensors, Sensors