


Danfoss AK-UI55 Function Remote Display Installation Guide

[Home](#) » [Danfoss](#) » Danfoss AK-UI55 Function Remote Display Installation Guide 

Danfoss AK-UI55 Function Remote Display




Contents


- [1 Installation Instruction](#)
- [2 Dimensions](#)
- [3 Documents / Resources](#)
- [3.1 References](#)

Installation Instruction


Danfoss 80G8237



Danfoss 80G8238




Danfoss 80G8239



Dimensions


Danfoss 80G8235



0 < t_{amb} < +55°C 32 < t_{amb} < +130 °F Non condensing




Danfoss 84B8280



Mounting kit for display type:
AK-UI55 Set
AK-UI55 Bluetooth



Documents / Resources

	Danfoss AK-UI55 Function Remote Display [pdf] Installation Guide AK-UI55 Function Remote Display, AK-UI55, Function Remote Display, Remote Display, Display
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.