

Danfoss Ally Zigbee Gateway



Danfoss Ally Zigbee Gateway User Guide

[Home](#) » [Danfoss](#) » Danfoss Ally Zigbee Gateway User Guide 

Contents

- [1 Danfoss Ally Zigbee Gateway](#)
- [2 Using Instruction](#)
- [3 Operating Instruction](#)
- [4 Safety precautions](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)




Danfoss Ally Zigbee Gateway



Using Instruction

Download the Danfoss Ally™ App and create your account.



works with the
Google Assistant




WORKS WITH
amazon alexa




smartheating.danfoss.com

Connect mains power and Ethernet cables to your Danfoss Ally™ Gateway and follow the installation process in the App. Make sure your mobile device is connected to Wi-Fi from the same router as the Gateway is connected to with cable.




1. Launch Danfoss Ally™ App and add your Danfoss Ally™ Gateway.
2. Select Danfoss Ally™ Gateway and add subdevices to your Danfoss Ally™ Smart heating system.



After the installation process is done, open the App and set up your heating system with the schedule and temperature. For the full information please visit the web address below.

ally.danfoss.com



Operating Instruction

	Room temperature
	Manual mode
	Heating schedule
	Away mode
	Pause
	At home mode
	Pre-Heat is used to ensure you have the right temperature when you want it. When the Pre-Heat symbol is showing it means that it is ramping up to the next scheduled At Home mode.

Safety precautions

SIMPLIFIED EU DECLARATION OF CONFORMITY

- Hereby, Danfoss A/S declares that the radio equipment type Danfoss Ally™ complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address: www.danfoss.com
- The gateway is not intended for children and must not be used as a toy. Do not leave packaging materials where children may be tempted to play with them, as this is extremely dangerous. Do not attempt to dismantle the gateway as it contains no user-serviceable parts.

Danfoss A/S


- 6430 Nordborg Denmark
- Homepage: www.danfoss.com.

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are the property of the respective companies.




Danfoss and the Danfoss logotype are trademarks of Danfoss A/S.

All rights reserved. AN342744095871EN-000102 © Danfoss.

Documents / Resources

	<p>Danfoss Ally Zigbee Gateway [pdf] User Guide Ally, Ally Zigbee Gateway, Zigbee Gateway, Gateway</p>
---	--

References

-  [Danfoss Ally™ | Danfoss](#)
-  [Danfoss Smartheating | Danfoss](#)
-  [Engineering Tomorrow | Danfoss](#)
- [User Manual](#)

