



Danfoss ECA 36 Internal Input-Output Module Installation Guide

[Home](#) » [Danfoss](#) » Danfoss ECA 36 Internal Input-Output Module Installation Guide 



ENGINEERING TOMORROW

Installation Guide

ECA 36 internal I/O module (code no. 087H3206)


ECA 37 sensor (code no. 087H3207)

Contents


- [1 ECA 36 Internal Input-Output Module](#)
- [2 Installation Guide, ECA 36 internal I/O module and ECA 37 sensor](#)
- [3 ECA 37 connection inlet](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

ECA 36 Internal Input-Output Module


ECA 36




Installation Guide, ECA 36 internal I/O module and ECA 37 sensor




ECA 37 connection inlet



A 37 connection outlet




Danfoss
67H12206.10



ECL 310 + ECA 36

Danfoss
67H12206.10



ECA 36 and ECA 37: www.danfoss.com



<https://www.youtube.com/user/DanfossHeating> -> Playlists -> How-to Videos -> District Energy installation videos

Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222


Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product. All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

410 Danfoss I DCS-SGDPT/DK 12022.12 AN43565202303400-000101



* 0 8 7 H 9 3 4 9 *

Documents / Resources



[Danfoss ECA 36 Internal Input-Output Module](#) [pdf] Installation Guide
ECA 36 Internal Input-Output Module, ECA 36, Internal Input-Output Module, Input-Output Module, Output Module, Module

References

-  [Danfoss - Engineering Tomorrow | Danfoss](#)