



Danfoss XM 205A Extension Module Instructions

[Home](#) » [Danfoss](#) » Danfoss XM 205A Extension Module Instructions 



Instructions
AK-XM 205A
REFRIGERATION AND AIR CONDITIONING


Contents

[1 XM 205A Extension
Module](#)

[2 Documents / Resources](#)

[2.1 References](#)

XM 205A Extension Module




Instructions RI8HL602 © Danfoss 09/2018 AK-XM 205A



080R9217



RI8HL602



[Danfoss XM 205A Extension Module](#) [pdf] Instructions
AKS 32R, AKS 2050, XM 205A Extension Module, XM 205A, Extension Module, Module

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.