

Dante MDM-T2 Music and Message Server Instruction Manual

Home » Dante » Dante MDM-T2 Music and Message Server Instruction Manual



Dante MDM-T2 Music and Message Server



Contents


- 1 MusiCall Music &
- Message
- 2 Software
- 3 Specifications
- **4 Customer Support**
- **5 Documents / Resources**
 - **5.1 References**
- **6 Related Posts**

MusiCALL systems with Dante® are easily expandable, need an extra speaker? Plug it in where you want!

Networks can be expanded and reconfigured at any Θ me with just a few clicks. If you compare a MusiCALL audio installa Θ on with a conven Θ onal audio system, it is striking how much fewer building blocks are needed to set up a complete system. Ease of installa Θ on is great for the installer.

The MDM-T series MusiCall Music & Message server is a desk version with 10.1" touchscreen. It can be used as central control unit and / or announcement console when combined with a microphone like MDM-MIC.





Software

The MusiCALL so Oware is packed with features:

Easy to use graphical interface

Priority messaging. Scheduled audio files (or manually triggered) to start on Θ me (such as class Θ mes at schools or commercials in shops)

Internetradio. Standard presets with 15 internet radiosta⊕ons, expandable.

Playlist player(for example themes in museums)

Priority annoucement. Groups or individual zones.

Auto start and stop of zones to save energy.

1 to 8 separate zones possible per main unit, upgradable.

Specifications

Hardware			
CPU	Intel Gemini Lake N4000 / N4120	Wifi	2.4 GHz & 5 GHz Dual frequency
Screen	G+G multi touch 10.1"	Blueto oth	Bluetooth 5.0
Resolution	1920 x 1200 (IPS)	Operat ing system	Windows IoT2021 LTSC
Graphics	Intel UHD 600	Wired networ k	1x RJ45 1000Mbps and 1x RJ45 1000Mbps via USB dongle
Memory	8GB	Ports	4x USB3.0 / 2x RS232
Storage	128GB EMMC drive and TF card slot	Headp hone j ack	Combo 3.5mm mic/headphone
Size	242 x 153 x 62mm	HDMI	2x HDMI 2.0 (4k support)
Operation te mperature	-10°C ~ 50°C	Weight	772g
Software			
Zone outputs	MDM-T2: 2 (Dante®) channels for 2 mo no zones or 1 stereo zone MDM-T4: 4 (Dante®) channels for 4 mo no zones or 2 stereo zones MDM-T8: 8 (Dante®) channels for 8 mono zones or 4 stereo zones	Inputs	MDM-T2: 8 (Dante®) channels MDM-T4: 8 (Dante®) channels MDM-T8: 8 (Dante®) channels
Online suppo	3 years included		

Customer Support

DATEQ International B.V.
De Paal 37, 1351 JG Almere, Netherlands **Tel:** + 31 36 5472222

E-mail: <u>info@dateq.nl</u>
Internet: <u>www.dateq.nl</u>
Chamber of Commerce: 84615559

Bank: IBAN NL 41 RABO 0375260307 Bank swift: RABO NL2U TVA/VAT: NL 863282313B01





Documents / Resources



<u>Dante MDM-T2 Music and Message Server</u> [pdf] Instruction Manual MDM-T2, MDM-T4, MDM-T8, MDM-T2 Music and Message Server, MDM-T2, Music and Message Server, Message Server, Server

References

- Dateq DATEQ
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.