



Dante NewHank DU 22 2 Channel USB Input or Output Adapter User Guide

[Home](#) » [Dante](#) » Dante NewHank DU 22 2 Channel USB Input or Output Adapter User Guide 

Contents

- [1 Dante NewHank DU 22 2 Channel USB Input or Output Adapter](#)
- [2 Product Introduction](#)
- [3 Product Feature](#)
- [4 Technical Parameters](#)
- [5 Product Overview](#)
- [6 Product Connect](#)
- [7 Packing List](#)
- [8 Warranty Card](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)



Dante NewHank DU 22 2 Channel USB Input or Output Adapter



Thank you for buying NewHank DU 22, this guide will take you know how to use this product.

Product Introduction

This product is applied to the audio system field to realize the USB signal and Dante network audio signal conversion function.

Product Feature

- 1. Function Introduction: Support USB signal and Dante network audio signal conversion
- 2. Input & Output:2 channel

Technical Parameters

Model No.	NewHank DU 22
Product Type	Audio signal adapter
Function	
	The USB signal and Dante network audio signal conversion
RJ45 Port	1
Connection	RJ45 and USB A type
Power supply	USB
Sampling rate	48kHz
Network transmission	Dante IP AES67 RTP audio
USB	Specification level USB 2.0 devices
Operating temperature	0-40°C
Size (LxWxH)	652mm x 32mm x 22mm
Weight	0.2kg

Product Overview




Product Connect

Follow the below steps to set up a Dante network for controlling.

- 1. Download and install the Dante Controller from Audinate website (www.audinate.com).
- 2. Connect the device to the switch using Dante network audio system with network cable
- 3. The analog audio transmission device is connected through the XLR interface
- 4. Search for devices in Dante Controller software, Select and open the devices to be configuredOn the Routing page, match the input row with the output column with a custom check.

5. Once set up and configured the audio routing between audio device, the audio device will remember and save the settings.



Packing List

- QC Card 1 Piece
- DU 22 1 Piece

Notes


In order to ensure the reliable use of equipment and the safety of personnel, please follow below details when installing, using and maintaining:

1. Keep the working environment well ventilated, so that the heat generated by the equipment can be discharged in time, so as not to damage the equipment due to high temperature.
2. Non-professionals without permission, do not dismantle the equipment without authorization, so as to avoid the risk of electric shock. Do not repair, so as not to increase the damage of the equipment.
3. Do not spill any corrosive chemicals or liquids on or near the equipment.

Warranty Card

- Date of production
- Model No.
- Serial No.

Documents / Resources

	<p>Dante NewHank DU 22 2 Channel USB Input or Output Adapter [pdf] User Guide</p> <p>NewHank DU 22, 2 Channel USB Input or Output Adapter, NewHank DU 22 2 Channel USB Input or Output Adapter, USB Input or Output Adapter, Input or Output Adapter, Input Adapter, Output Adapter, Adapter</p>
--	--

References

-  [Audinate - Maker of Dante, Pro AV's Leading Networking Technology](#)