



## DAS-4 LD11 LCD Screen User Manual

[Home](#) » [DAS 4](#) » DAS-4 LD11 LCD Screen User Manual 


# DAS-4

LD11 User Manual  
LCD screen


### Contents

- 1 REGULAR DISPLAY AND BUTTON OPERATION HOW TO CHANGE THE DISPLAY MODE
- 2 HOW TO DISPLAY CALENDAR
- 3 HOW TO SET NORMAL TIME
- 4 HOW TO USE TIMER
- 5 CARE OF YOUR WATCH
- 6 FEATURES AND SPECIFICATIONS
- 7 Documents / Resources
- 8 Related Posts


## REGULAR DISPLAY AND BUTTON OPERATION




## HOW TO CHANGE THE DISPLAY MODE




## HOW TO DISPLAY CALENDAR




HOW TO SET NORMAL TIME




HOW TO SET NORMAL TIME




HOW TO SET ALARM TIME




HOW TO SET ALARM TIME




## HOW TO SET THR ALARM RINGING ON THE HOUR AND KEY TONE




## HOW TO SET THR ALARM RINGING ON THE HOUR AND KEY TONE




### HOW TO USE THR CHRONOGRAPH




### HOW TO USE THR CHRONOGRAPH




## HOW TO USE TIMER




## HOW TO USE TIMER



## HOW TO SET SECOND TIME ZONE



## HOW TO USE EL LIGHT



## CARE OF YOUR WATCH

1. This watch contains precision electronic components. Never attempt to open the case or remove the back cover.
2. Do not operate buttons while underwater, or while swimming or diving.
3. Should water or condensation appear in the watch, immediately have the watch checked? Water can corrode electronic parts inside the case.
4. Avoid severe impact: The watch is designed to withstand impact under normal use. Do not subject it to severe impacts or rough usage, and do not drop it onto hard surfaces.
5. Avoid exposing the watch to temperature extremes.
6. Clean the watch with a soft cloth and clean water only. Avoid using chemicals, especially soap.
- 7.

Keep your watch away from strong electric fields and static electricity.


## FEATURES AND SPECIFICATIONS

1. Standard display mode: Hour, Minutes, Seconds, Month, Day of the week.
2. Function:
  - Month, Date AM/PM and Electro-Luminescent light.
  - Alarm function with buzzer signal output
  - Chronograph function with lap operation.
  - Hourly chime.
  - 12(24-hour format switch option.
  - Timer.
  - Second-time zone.
3. Accuracy at normal temperature (25t):  $\pm 30$  seconds a month.
4. Normal operating temperature range: 10t 40t.

The warranty terms that cover the product are mentioned in detail on the official website [www.das-4.com](http://www.das-4.com)

Waterproof up to 100 meters depth  
[www.das-4.com](http://www.das-4.com)

## Documents / Resources

	<p><a href="#">DAS-4 LD11 LCD Screen</a> [pdf] User Manual LD11, LCD Screen</p>
---	---

Manuals+.