



Dash 12” Pizza Stone User Manual

[Home](#) » [Dash](#) » Dash 12” Pizza Stone User Manual 

Contents

- [1 Dash 12” Pizza Stone User Manual](#)
- [2 Use & Care](#)
- [3 WARRANTY](#)
- [4 Related Posts](#)

Dash 12” Pizza Stone User Manual



Use & Care

Before each use, pre-heat the Pizza Stone in the Dash Chef Series Air Fryer Oven for 10 minutes. The Pizza Stone is sensitive to quick temperature changes.

Remove the pre-heated Pizza Stone from the Dash Chef Series Air Fryer Oven and place pizza or bread directly

on the surface. Be sure to use a protective, heat-safe oven glove when removing or handling the pre-heated Pizza Stone. Place the Pizza Stone in the Chef Series Air Fryer Oven and cook per recipe directions.

When finished, allow the Pizza Stone to cool on a stovetop or trivet. Do not cool by placing directly under cold water or on a cold countertop: this may cause the Pizza Stone to crack.

Soaking in water may cause the stone to weaken. Use a stiff brush and warm water to clean after use, then air dry and store in a dry place.

Do not use soaps, detergents, or other cleaning solutions on the Pizza Stone. The Pizza Stone is NOT dishwasher safe.



WARRANTY

STOREBOUND, LLC – 1 YEAR LIMITED WARRANTY

Your StoreBound product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, StoreBound, LLC will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. StoreBound will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to support@storebound.com.

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. STOREBOUND SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION

OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state. Our US-based customer support team is at your service Monday – Friday during the times below. Reach us at 1 (800) 898-6970 7am-7pm Pacific Time Zone or support@bydash.com

DAFT2300UPPS01_20191016_v2 Made in China

Download

Dash 12" Pizza Stone User Manual – [[Download PDF](#)]
