



DATRON TW-7000 Voice Enhancement Option User Manual

[Home](#) » [DATRON](#) » DATRON TW-7000 Voice Enhancement Option User Manual 

Contents

- [1 DATRON TW-7000 Voice Enhancement Option](#)
- [2 INTERNAL OPTIONS](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

DATRON

DATRON TW-7000 Voice Enhancement Option



INTERNAL OPTIONS

This chapter covers internal options that can be added to the TW7000. They are generally factory installed. If added in the field, installation requires a #2 Phillips-head screwdriver and a board puller included in the following

maintenance kits.

- 7000EXT extender kit
- TW7000TK tool kit

INTERNAL OPTIONS

Part Number

See Page

Additional Channel	7000ACH	6-2
ALE	7000ALE	6-3
Clock	7000CLK	6-19
Data Interface RS422/423/485	7000RS	6-20
Encryption	7000ENCR	6-21
FSK Remote Control	7000RF	6-21
High Stability	7000HS	6-34
ISDN Remote Control	7000RI	6-42
Narrowband CW Filter	7000CW	6-55
Noise Blanker	7000NB	6-56
Recorder	7000RCDR	6-62
Selcall, Transcall and TransAdapt	7000TC	6-63
Voice Enhancement Module	7000VEM	6-64
Wideband Data Filter	7000WB1	6-64

For information on changing the on or off status of these options, refer to the TW7000-MSOP operator manual.


Voice Enhancement Option (7000VEM)

This option provides superior voice recognition and signal-quality improvement in noisy environments.

To install this option:

- 1. Turn the TW7000 off and remove the top cover.
- 2. Remove the board hold-down bars.
- 3. Install the VEM board into the OPTI slot.
- 4. Replace the cover.

Documents / Resources

	DATRON TW-7000 Voice Enhancement Option [pdf] User Manual TW-7000 Voice Enhancement Option, TW-7000, Voice Enhancement Option, Enhancement Option
---	---