



David Clark C3821 Radio Interface Cord Installation Guide

[Home](#) » [David Clark](#) » David Clark C3821 Radio Interface Cord Installation Guide 

David Clark C3821 Radio Interface Cord Installation Guide



Contents

[1 INSTALLATION INSTRUCTIONS C3821 RADIO INTERFACE CORD](#)

[1.1 DESCRIPTION](#)

[1.2 INSTALLATION](#)

[2 Documents / Resources](#)

[3 Related Posts](#)

INSTALLATION INSTRUCTIONS C3821 RADIO INTERFACE CORD

DESCRIPTION

The C3821 Radio Interface Cord provides connection between the Series 3800 Communication System and the user's mobile radio. When the C3821 is connected to a Radio Interface Module the mobile radio receive and transmit functions become part of the intercom system.

NOTE: Ensure that cable connections at the radio end are clean and secure.

INSTALLATION

1. Connect the stripped and tinned ends of the C3821 Radio Interface Cord to the mobile radio following the schematic shown below.
2. The C3821 has a military type screw-on connector. Install as follows:
 - Align key-way slot on cord connector with key in threaded connector on module.
 - Insert pins into socket until firmly seated.
 - Hand tighten swivel nut on cord connector.





Figure 1. Model C3821 Radio Interface Cord Schematic Diagram.

Documents / Resources

 DAVID CLARK COMMUNICATIONS 10000 W. 10th Ave., Suite 100 Denver, CO 80231 Tel: 303.751.1000 Fax: 303.751.1001 www.davidclark.com	David Clark C3821 Radio Interface Cord [pdf] Installation Guide C3821, Radio Interface Cord
--	--