



DAVIS Vantage Vue Weather Station User Guide

[Home](#) » [DAVIS](#) » DAVIS Vantage Vue Weather Station User Guide 

DAVIS Vantage Vue Weather Station User Guide



Contents

1 INSTRUCTIONS


2 Documents / Resources

2.1 References

3 Related Posts

INSTRUCTIONS


1. Prepare the Sensor Suite: attach wind cups and wind vane; pull tab on battery (or install battery if not included); install debris screen and rain collector tipping spoon assembly



2. If using WeatherLink Live, download the WeatherLink app. If using a Console, install power and set up the Console.




3. Verify data transmission from the Sensor Suite to the WeatherLink app and/or to the Console.



Note: For best reception during this step, WeatherLink Live and/or Console and the Sensor Suite should be at least 10 feet (3 meters) apart. (Initial reception typically takes 1-3 minutes but can take up to 10 minutes depending on specific environmental conditions.)

4. Mount the Sensor Suite to its outside mounting pole.



Please refer to your manuals for detailed instructions.
Manuals can be downloaded at www.davisinstruments.com/vv-manual.

Copyright ©2021 Davis Instruments Corp. All rights reserved.
07395.257 Rev. E 7/19/2021





[DAVIS Vantage Vue Weather Station](#) [pdf] User Guide
Vantage Vue, Weather Station, Vantage Vue Weather Station

References

- [D Vantage Vue - Davis Instruments Support, FAQs and Troubleshooting](#)