



DECODER DVB-T2 TV Stick Instruction Manual

[Home](#) » [DECODER](#) » DECODER DVB-T2 TV Stick Instruction Manual

Contact us for help: dcolorteam@gmail.com

High Definition Digital Terrestrial Receiver
H.265 DVB-T2 TV Stick



Simply Upgrade your TV DVB-T2
Happy? Tell the whole world
Unhappy? Contact us to get help



Contents [[hide](#)]

- 1 Packing list
- 2 Functional Port
- 3 Upgrade to DVB-T2
- 4 Attention
- 5 DVB Remote Control
- 6 Remote Auto -learning Set
- 7 Troubleshooting
- 8 Documents / Resources
- 9 Related Posts

Packing list



x1



x1




x1




x1

Functional Port




Upgrade to DVB-T2




Attention

1. Place the IR Receiver in front of your TV
Not behind it



2. Insert 2 AAA batteries (not included) into you're remote



DVB Remote Control



 **POWER:** turn ON/OFF the DVB device

TV Control

 **POWER:** turn ON/OFF the TV

 **SET:** auto-learning setting


MEDIA Control


 **PVR:** Show the REC media via the USB device

 **Y-FORMAT:** Switch 720P or 1080P


 **ASPECT:** Switch 16:9 or 4:3


 **TIMER:** Book listing control

 **SUB-T:** Show the subtitles (if available)

 **RECALL:** Skips to the previous channel

MENU Control


 **EPG:** Electronic guide (if available)

 **INFO:** Info of the channel


 **MENU:** open the main menu

 **EXIT:** Exit from a menu

MORE Control

 **AUDIO:** selects the language of the channel

 **TTX:** teletext (if available)

 **FAV:** creates and shows the list of the favorite channels

 **REC:** start recording in the USB device

 **PAGE:** navigate inside the menu

CHANNEL Control:

TV/RADIO: switch TV or Radio channel

Remote Auto -learning Set



Only these 4 keys of DVB remote can be learned,

Use as an example

All these keys can be set up via steps 1~5

① DVB Remote

SET

5"

ON

Press on 5 seconds Until the POWER LED lights ON

② DVB Remote

VOL+

Flash

Press the learning key The POWER LED lights Flash

③ Face to Face in 10cm

Face the remote to each other within 10 cm

④ TV Remote

+

ON

Press the learned key The POWER LED lights ON

⑤ DVB Remote

SET

Press the SET key, DONE!

Troubleshooting

Problem	Possible cause	Solutions
The front panel display does not turn on	Lack of tension	Make sure the power cord is properly inserted into a powered outlet. Verify that the switch is turned on.
No image or sound	The cables connecting the TV and the decoder are not connected correctly	Check that the output signal cable is well connected (SCART or HDMI). Also, check the antenna cable.
	TV mode is incorrect	Make sure you have selected the correct input signal on the TV (SOURCE or INPUT key on the TV remote control).
	Incorrect video definition	Press V-FORMAT on the remote control and select a video resolution that allows correct viewing.

Intermittent t picture and a udio	Insufficient signal strength	Check that the antenna cable is well connected and that the quality of the video signal is adequate.
	Electrical interference	Check that the antenna cable is completely shielded
No audio	The receiver or TV is in silent m ode	Disable silent mode using the MUTE button
	Volume level too low	Check that the volume level of the set-top box and television are adequate
	Audio CODEC is not supported	While watching multimedia content, audio encoding may not be supported (while video encoding maybe) and movies may appear without audio. The file is not completely readable.
The remote c ontrol not wor king	Batteries not inserted	Insert the batteries into the remote control
	Low battery	Replace the batteries
	Polarity reversal of batteries	Check that the batteries have been inserted according to their correct polarity, as indicated on the bottom of the battery compartment.
	The remote control is out of its o perating range	Approach and point the remote control directly at the appliance.
Media files on the USB stick are not playe d	The files are not of the supporte d format	Only some formats are supported
	The compression codec is not s upported	Only some codecs are supported

Documents / Resources



[DECODER DVB-T2 TV Stick](#) [pdf] Instruction Manual

DVB-T2 TV Stick, DVB-T2, TV Stick