



DEEPCOOL AG400 Series Single Tower CPU Cooler Installation Guide

[Home](#) » [DEEPCOOL](#) » DEEPCOOL AG400 Series Single Tower CPU Cooler Installation Guide 

Contents

- 1 AG400 Series
 - 1.1 Single-Tower CPU Cooler
 - 1.2 AG400 ARGB AG400 BK ARGB AG400 WH ARGB
 - 1.3 INTEL & AMD
 - 1.4 INTEL LGA1200 • LGA1151 • LGA1150 • LGA1155
 - 1.5 INTEL LGA1700
 - 1.6 AMD AM5 • AM4
 - 1.7 Connection
 - 1.7.1 Warranty information Description of limited liability warranty
 - 1.7.2 Support and services
- 2 Documents / Resources
- 3 Related Posts

AG400 Series

Single-Tower CPU Cooler

AG400 ARGB
AG400 BK ARGB
AG400 WH ARGB








INTEL & AMD


<div data-bbox="220 181 456 459" data-label="Image"> </div> <div data-bbox="518 114 558 152" data-label="Text"> <p>A</p> </div> <div data-bbox="518 495 558 533" data-label="Text"> <p>x1</p> </div>	<div data-bbox="662 188 927 452" data-label="Image"> </div> <div data-bbox="981 120 1018 159" data-label="Text"> <p>B</p> </div> <div data-bbox="970 488 1013 526" data-label="Text"> <p>x1</p> </div>	<div data-bbox="1114 188 1380 452" data-label="Image"> </div> <div data-bbox="1444 120 1481 159" data-label="Text"> <p>C</p> </div> <div data-bbox="1433 488 1476 526" data-label="Text"> <p>x1</p> </div>
<div data-bbox="215 712 461 819" data-label="Image"> </div> <div data-bbox="523 645 560 683" data-label="Text"> <p>D</p> </div> <div data-bbox="513 855 557 893" data-label="Text"> <p>x1</p> </div>	<div data-bbox="721 676 860 855" data-label="Image"> </div> <div data-bbox="981 609 1018 647" data-label="Text"> <p>E</p> </div> <div data-bbox="970 889 1013 927" data-label="Text"> <p>x4</p> </div>	<div data-bbox="1177 676 1318 855" data-label="Image"> </div> <div data-bbox="1444 609 1481 647" data-label="Text"> <p>F</p> </div> <div data-bbox="1433 889 1476 927" data-label="Text"> <p>x4</p> </div>
<div data-bbox="266 1088 405 1274" data-label="Image"> </div> <div data-bbox="523 1021 560 1059" data-label="Text"> <p>G</p> </div> <div data-bbox="513 1308 557 1346" data-label="Text"> <p>x4</p> </div>	<div data-bbox="740 1088 841 1274" data-label="Image"> </div> <div data-bbox="981 1021 1018 1059" data-label="Text"> <p>H</p> </div> <div data-bbox="970 1308 1013 1346" data-label="Text"> <p>x4</p> </div>	<div data-bbox="1200 1072 1300 1288" data-label="Image"> </div> <div data-bbox="1452 1008 1476 1046" data-label="Text"> <p>I</p> </div> <div data-bbox="1433 1323 1476 1361" data-label="Text"> <p>x4</p> </div>



LGA1200
LGA115X













4-PIN/CPU_FAN/CPU_OPT

INTEL

LGA1700










4-PIN/CPU_FAN/CPU_OPT

AMD


AM5 • AM4







Connection



Warranty information
Description of limited liability warranty

1. Warranty is provided for abnormal or damaged parts of this product due to defects in the manufacturing process; the abnormal or damaged parts in the following cases will be repaired or replaced by DeepCool after inspection and judgment; any abnormality or damage to any part of the product will not be covered by the warranty if the unit is used outside of the following conditions:
 - The normal use of the product in accordance with the product manual, without improper or excessive use, or in any other unreasonable application (for example: using this product in product testing).
 - Damages that are not caused by acts of nature (for example: lightning, shock, power surge, fire, earthquake, flood, blizzard, hurricane, insects, animal attack, etc.).
 - The product has not been disassembled, modified, or repaired by any unauthorized person. The components have not been disassembled or replaced.
 - The product's tamper-evident sticker has not been removed or damaged.
2. During the warranty period, DeepCool's greatest share of liability is limited to the value of this product in the current market (the current residual value of the product does not include freight, handling fees, and other costs). DeepCool shall not be liable for compensation for other losses caused by the use of this product.
3. During the warranty period, DeepCool is obligated to repair or replace defective products. However, under any circumstances, DeepCool shall not be liable for any compensation for any losses (including but not limited to data damage, business loss, loss of profit, incidental or indirect loss of using this product, improper use and losses caused by the user's negligence whether it is foreseeable or DeepCool has notified in advance that such damage may occur, but the user still violates the warranty terms and contract) caused by the sale, purchase or use of this product.
4. The warranty clause is only applicable to the original buyer who purchases the product through a DeepCool authorized distributor or agent, and not applicable to the buyer who purchases it second hand.
5. In order to protect your rights, please keep and provide the proof of purchase (receipt or invoice). The proof must clearly indicate the date of purchase to determine the warranty period.

Support and services

If you have any questions or encounter any problems during the warranty period, please feel free to contact a DeepCool authorized dealer, agent, or visit our official website:

<https://www.deepcool.com/support>. Please provide a detailed description of the problem and proof of purchase when contacting the DeepCool Support Team. Thank you for purchasing DeepCool products.

You are kindly required to:



- Provide proof of purchase with the date of purchase and product purchased clearly shown.
- Bear the shipping cost of sending the defective product to DeepCool authorized dealers and agents (including transit shipment fee), and DeepCool authorized dealers and agents will bear the cost of returning the repaired product to you (including transit shipment fee).
- Visit <https://www.deepcool.com/support> for more information if there are any other outstanding issues or updated warranty terms which will be published on the official DeepCool website.


11650 Mission Park Drive Suite 108., Rancho Cucamonga, CA 91730
Beijing DeepCool Industries Co., Ltd.
Building 10, No. 9 Dijin Road, Haidian District Beijing 100095, China

© 2022 Beijing DeepCool Industries Co., Ltd. All rights reserved.
" DEEPCOOL " and other commercial identities are legitimate registered trademarks and commercial identities of the trademarks owner and its affiliates in China and other countries or regions.
Pictures on this package are for reference only, please refer to the actual product.

For more information, please check our website at: www.deepcool.com

www.deepcool.com

Documents / Resources

	<p>DEEPCOOL AG400 Series Single Tower CPU Cooler [pdf] Installation Guide</p> <p>AG400 Series Single Tower CPU Cooler, AG400 Series, AG400 Series CPU Cooler, Single Tower CPU Cooler, Tower CPU Cooler, Single CPU Cooler, CPU Cooler, Cooler, AG400 ARGB, AG400 BK ARGB, AG400 WH ARGB</p>
--	--