



DEEPCOOL FH-04 4 Port Fan Hub Installation Guide

[Home](#) » [DEEPCOOL](#) » DEEPCOOL FH-04 4 Port Fan Hub Installation Guide 



FH-04 4 Port Fan Hub Installation Guide



Contents

- [1 FH-04 4 Port Fan Hub](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)


FH-04 4 Port Fan Hub

This installation guide is applicable for FAN HUB series.

PRODUCT SCHEMATIC DRAWING


How to Use

Tear off the foil to stick the device



This fan hub supports up to 4 fans, PWM function compatible.

Note: The data of FAN 1 can be obtained by BIOS or other software, PWM function is not available when 3-Pin port is applied.



for more information please check our website at: www.deepcool.com

DeepCool USA Inc.

11650 Mission Park Drive Suite 108 Rancho Cucamonga, CA 91730 Beijing DeepCool Industries Co., Ltd.


Building 10, No. 9 Dijin Road, Haidian District, Beijing 100095, China

© 2021 Beijing DeepCool Industries Co., Ltd. All rights reserved.

DEEPCOOL "and other commercial identities are legitimate registered trademarks and commercial

identities of the trademarks owner and its affiliates in China and other countries or regions. Pictures on this package are for reference only, please refer to the actual product.

Documents / Resources

	DEEPCOOL FH-04 4 Port Fan Hub [pdf] Installation Guide FH-04, 4 Port Fan Hub, FH-04 4 Port Fan Hub, Fan Hub, Hub
---	---

[Manuals+](#)