



# DEFINITIVE TECHNOLOGY Dymension DM10 Compact Center Channel Speaker User Guide

[Home](#) » [DEFINITIVE TECHNOLOGY](#) » **DEFINITIVE TECHNOLOGY Dymension DM10 Compact Center Channel Speaker User Guide** 

## Contents

- [1 DEFINITIVE TECHNOLOGY Dymension DM10 Compact Center Channel Speaker](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Unpack](#)
- [5 Place](#)
- [6 Connection](#)
- [7 Setup Is Complete!](#)
- [8 More Information](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)



**DEFINITIVE TECHNOLOGY Dymension DM10 Compact Center Channel Speaker**




## Product Information

The product is a speaker named DM10TM manufactured by Dymension. The user manual is in the form of a PDF file named HBP4777\_Dymension\_QSG\_DM10\_LPP\_2022-07-29.pdf. The speaker is designed to be connected to an amplifier and can be placed near the center of a television. The packaging includes the speaker and speaker wires.

## Product Usage Instructions


1. Unpack the speaker and ensure all items are included in the box.
2. Place the speaker as close to the center of your TV as possible. If placing it inside a shelf, ensure there is at least 1-2 inches (2.5-5 cm) of space between the top of the speaker and the shelf. Refer to the online user manual for placement suggestions.
3. Connect speaker wires to the binding posts on the speaker. To do this, strip about 3/8 inch (10 mm) of insulation from two speaker wires, unscrew the binding posts, connect the wires to the binding posts, and tighten the binding posts until secure.
4. Connect the speaker wires to your amplifier.
5. Adjust the settings on your amplifier and test the speaker sound and volume by listening to music or watching TV. Scan the QR code to download the user manual, view frequently asked questions, or get troubleshooting assistance.

## Unpack



- Check that the items shown are included in the box.


## Place



- Place the speaker as close to the center of your TV as possible. If you're placing the speaker inside a shelf, make sure there's at least 1-2 in (2.5-5 cm) of space between the top of the speaker and the shelf.
- Refer to the online user manual for placement suggestions.

## Connection


### Connect Speaker Wires to the Binding Posts



1. Strip about 3/8 in (10 mm) of insulation from two speaker wires.
2. Unscrew the binding posts.
3. Connect the wires to the binding posts.
4. Tighten the binding posts until secure.


### **Connect the Speaker Wires to Your Amplifier**






- Connect the other ends of your speaker wires to your amplifier. Ensure that the speaker is always connected to the receiver or amplifier + to + and – to –.

**Setup Is Complete!**



- Adjust the settings on your amplifier, then listen to music or watch TV to test the speaker sound and volume.
- Scan the QR code to download the user manual, see frequently asked questions, or get troubleshooting assistance.



- [support.definitivetechology.com](https://support.definitivetechology.com)

## More Information



- #Dymension

## Sound United, LLC

- 5541 Fermi Court
- Carlsbad, CA 92008 U.S.A

## EU Contact

- Sound United Europe, A division of D&M Europe B.V.
- Beemdstraat 11, 5653 MA
- Eindhoven, The Netherlands

## UK Importer

- D&M Audiovisual Ltd.
- Dale Road, Worthing, West Sussex
- BN11 2BH United Kingdom

## Documents / Resources

	<p><b><a href="#">DEFINITIVE TECHNOLOGY Dymension DM10 Compact Center Channel Speaker</a></b> [pdf] Use r Guide</p> <p>DM10TM, Dymension DM10 Compact Center Channel Speaker, Dymension DM10, Compact C enter Channel Speaker, Center Channel Speaker, Speaker</p>
---	--

References

-  [Support Home Page](#)