

DEKOLIGHT
348127 Deko Uni
II Max Tilt



DEKOLIGHT 348127 Deko Uni II Max Tilt Installation Guide

[Home](#) » [DEKOLIGHT](#) » DEKOLIGHT 348127 Deko Uni II Max Tilt Installation Guide 

Contents

- [1 DEKOLIGHT 348127 Deko Uni II Max Tilt](#)
- [2 Specifications](#)
- [3 Mounting Instructions](#)
- [4 Frequently Asked Questions](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)



DEKOLIGHT 348127 Deko Uni II Max Tilt


**Attention!**

For this work, you must turnoff the power supply.

Specifications

- Article No.: 348127 / 348176
- Type: Surface-mounted ceiling lamp Uni II Max
- Input: 220-240V AC, 50-60Hz
- Power: 32.00W

Mounting Instructions



1. Identify the mounting location on the ceiling for the surface-mounted ceiling lamp.
2. Ensure the power source is switched off before starting the installation process.
3. Use appropriate tools to secure the lamp base to the ceiling following the provided guidelines.
4. Connect the blue wire (N) to the corresponding terminal and the brown wire (L) to its terminal.
5. Secure all connections properly and ensure there are no loose wires.

Frequently Asked Questions

Q: Can this ceiling lamp be dimmed?

A: No, this model does not support dimming functionality. It operates at a fixed brightness level.

Q: What is the recommended maintenance for this product?


A: To ensure optimal performance, regularly clean the lamp surface with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

Deko-Light Elektronik-Vertriebs GmbH 10.05.2022

www.deko-light.com / deko@deko-light.com

Technical Data can be changed without advance notice. Errors excepted.

Documents / Resources



DEKOLIGHT 348127 Deko Uni II Max Tilt [pdf] Installation Guide
348127 Deko Uni II Max Tilt, 348127, Deko Uni II Max Tilt, Uni II Max Tilt, Max Tilt, Tilt

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.