



DELSEY TSAlock-JYB103 TSA Code-Lock

[Home](#) » [DELSEY](#) » DELSEY TSAlock-JYB103 TSA Code-Lock 

Contents

- [1 DELSEY TSAlock-JYB103 TSA Code-Lock](#)
- [2 INSTRUCTIONS FOR USING THE TSA CODE-LOCK](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

DELSEY
PARIS

DELSEY TSAlock-JYB103 TSA Code-Lock



shutterstock.com - 490240792

INSTRUCTIONS FOR USING THE TSA CODE-LOCK


The Transport Security Administration (TSA) now allows you to lock your checked baggage with TRAVEL

SENTRY™ CERTIFIED locks.


Your resettable combination lock is preset to open at 0-0-0, even though dials might be positioned at other numbers. To modify the combination

1. Open the lock (using the original code 0-0-0).
2. Press the reset button (A) firmly with a pen (or other sharp object) until you hear a “click”. Keep the button pressed in.
3. Set your chosen secret combination by turning the thumbwheels (e.g.: 8-8-8).
4. Push the button (B) and allow the Button (A) to return to its original position.

Your personal code is now set. Note it down in a safe place in case you forget it.
If you wish to change the combination, repeat steps 2-4.



Documents / Resources

	<p>DELSEY TSAlock-JYB103 TSA Code-Lock [pdf] Instruction Manual TSAlock-JYB103, TSA Code-Lock</p>
---	---