



Delta FO202 Keyboard Mouse Adapter User Manual

[Home](#) » [Delta](#) » Delta FO202 Keyboard Mouse Adapter User Manual 


Delta FO202 Keyboard Mouse Adapter User Manual



Contents

- [1 XBOX ONE](#)
 - [1.1 Installation](#)
- [2 PLAYSTATION 4](#)
 - [2.1 Installation](#)
- [3 NINTENDO SWITCH](#)
 - [3.1 Installation](#)
- [4 MOUSE SENSITIVITY](#)
- [5 F0202 Delta Keymap Program \(Only Remap Keyboard Key\)](#)
 - [5.1 Ps4 Default KeyMap Guide](#)
 - [5.2 Xbox One Default KeyMap Guide](#)
 - [5.3 Nintendo Switch Default KeyMap Guide](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

XBOX ONE




Installation

1. Power off your Xbox One Standard Wireless Controller then connect it to the Adapter with a Charge & Sync cable.
2. Plug in your Keyboard&Mouse to the Adapter. Plug in the Adapter to your Xbox One console. The left indicator lights up and the right indicator flashes for a few seconds then lights up. Now you can use the keyboard&mouse instead of game controller.

NOTE:

- If the keyboard&mouse do not work after you plug in everything. Please re-plug the keyboard, mouse, controller and the Adapter until both indicators are always on.
- The controller must be Microsoft Official Xbox One Standard Controller and in power off status before connecting. Xbox One Elite Controller and other controllers can't get the Adapter to work.
- The cable that connect the controller to Adapter must be charge&sync cable.

PLAYSTATION 4



Installation


1. Power off your Sony DualShock 4 Wireless Controller then connect it to the Adapter with a Charge & Sync cable.

2. Plug in your Keyboard&Mouse to the Adapter.
3. Plug in the Adapter to your PS4 console. The left indicator lights up and the right indicator flashes for a few seconds then lights up. Now you can use the keyboard&mouse instead of game controller.

NOTE:

- if the keyboard&mouse do not work after you plug in everything. Please re-plug the keyboard, mouse, controller and the Adapter until both indicators are always on.
- The controller must be Sony Official DualShock 4 Wireless Controller and in power off status before connecting.
- The cable that connect the controller to Adapter must be charge&sync cable.

NINTENDO SWITCH



Installation

1. Turn on your Switch and Go to “Settings” – “Controllers and Sensors” – “PRO Controller Wired Communication” then click ON. Back to HOME menu.
2. Plug in your Keyboard&Mouse to the Adapter.
3. Plug in the Adapter to your Switch console. The left indicator lights up. The right indicator flashes.
4. Press Ctrl+2(@) then the right indicator will light up. Now you can use the keyboard&mouse instead of game controller.


NOTE:

- Do not control the Pro or JoyCon controller in game, or the keyboard will be disconnected.
- You must turn on the “PRO Controller Wired Communication” or you will get an error message.
- If the keyboard&mouse do not work after you plug in everything. Please re-plug the keyboard, mouse and the Adapter until both indicators are always on.

MOUSE SENSITIVITY

Mouse Sensitivity Priorities:


1. Adjust the mouse DPI to the best;
2. Adjust the controller sensitivity in game setting to the best;
 1. While you move the mouse but the view doesn't move accordingly. Decrease the Right Stick Dead Zone in game setting.
 2. While you move the mouse slightly but the view move too fast. Increase the Right Stick Dead Zone in game setting.
 3. If you feel the mouse horizontal movement speed inappropriate. Adjust the Horizontal Sensitivity in game setting.
 4. If you feel the mouse vertical movement speed inappropriate. Adjust the Vertical Sensitivity in game setting.
3. Press F3/4 to adjust the mouse sensitivity.



F0202 Delta Keymap Program (Only Remap Keyboard Key)


Download the keymap program on www.darkwalkerpro.com/download

Ps4 Default KeyMap Guide




Xbox One Default KeyMap Guide


Xbox One Default KeyMap Guide



Nintendo Switch Default KeyMap Guide



Documents / Resources

	Delta FO202 Keyboard Mouse Adapter [pdf] User Manual FO202, Keyboard Mouse Adapter
---	---