




# DELTACO SH-P03USB2 Smart Home Branch Socket User Manual

[Home](#) » [DELTACO](#) » DELTACO SH-P03USB2 Smart Home Branch Socket User Manual 

# DELTACO

## A NORDIC BRAND

SH-P03USB2 Smart Home Branch Socket  
User Manual



SH-P03USB2  
SMART OUTLET

### Contents

- [1 SH-P03USB2 Smart Home Branch Socket](#)
- [2 Install and use](#)
- [3 Cleaning and maintenance](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)

SH-P03USB2 Smart Home Branch Socket



## Thank you for choosing Deltas!

1. On/off/reset button
2. LED indicators for on/off status
3. USB-A output ports (Only power. No data)

### Reset

Press and hold about 6 seconds for reset. LED flashes quickly.

### Install and use

1. Download and install the app “Deltas smart home” from Apple App Store or Google Play Store on your mobile device.
2. Launch the app “Deltas smart home”.
3. Create a new account or log in to your existing account.
4. Tap “+” to add the device.
5. Choose category and then the type of product from the list.
6. Connect the device to power.
7. If the LED/lamp does not flash: Reset the device.  
If the status indicator flashes: Confirm in the app.
8. Confirm the Wi-Fi network and password.
9. Enter the device name.  
If you want to add the product to Google Home or Amazon Alexa, search for “Deltas Smart Home” in the Google Home or Amazon Alexa app and login to your Deltas Smart Home account. You might need to choose “discover devices” or add the product manually in the Google Home or Amazon Alexa app before you can use it.

### Add service to Google home

Add the device to google home.

Add the service “Deltas Smart Home”.

### Add device to Amazon Alexa

Use the menu “Skills & Games” and search for “Deltas Smart Home”. Enable the app and login. Use discover to add the device.

