



# DELTACO TB-802 Wireless Keyboard User Manual

[Home](#) » [DELTACO](#) » DELTACO TB-802 Wireless Keyboard User Manual

Contents [ [hide](#) ]

1 DELTACO TB-802 Wireless Keyboard

2 Charging the battery

3 Cleaning and maintenance

4 Support

5 KEYBOARD

6 Documents / Resources

6.1 References

7 Related Posts

DELTACO

## DELTACO TB-802 Wireless Keyboard



### Charging the battery

#### Safety instructions

1. Keep the product away from water and other liquids.


## Cleaning and maintenance

Clean the keyboard with a dry cloth. For difficult stains use a mild detergent.

## Support

More product information can be found at [www.deltaco.eu](http://www.deltaco.eu) Contact us by [e-mail: help@deltaco.eu](mailto:help@deltaco.eu)

## KEYBOARD

- FN + F1 = Open media player
- FN + F2 = Reduce volume
- FN + F3 = Increase volume
- FN + F4 = Turn sound on or off (mute)
- FN + F5 = Previous song
- FN + F6 = Next song
- FN + F7 = Play / pause
- FN + F8 = Stop
- FN + F9 = Open browser
- FN + F10 = Open email
- FN + F11 = Open my computer window
- FN + F12 = Open my favorites
- FN +  = Open search window

When Numlock is turned on, the LED changes to green for about 5 seconds, and then the LED turns off to save power.

The power switch and Micro USB-B charge port.



## LED status

Low battery: LED is yellow. Charging: LED is red. Caps lock is on: LED is blue. Numlock is on: LED is green.

## Connect

Connect the USB receiver to a USB port on the computer. Use the power switch on the keyboard to turn it on. The keyboard will connect automatically.

## Documents / Resources



## References

- [Pages - Home](#)