



DELUX M618mini Wireless Vertical Mouse User Manual

[Home](#) » [DELUX](#) » DELUX M618mini Wireless Vertical Mouse User Manual 

DELUX

M 618 mini Wireless Vertical Mouse
User Manual



Thank you for choosing our wireless vertical mouse.
Please read the user manual carefully when using this product.


Contents

- [1 Contents:](#)
- [2 Button Function:](#)
- [3 Specification](#)
- [4 Connection](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

Contents:

- Wireless vertical mouse: X1
- User manual: X1
- USB Nano receiver (stored in the battery compartment): X1
- 1.4 m Type-C charging cable: X1

Button Function:



1. Forward
2. DPI cycle
3. Backward
4. Scroll wheel
5. Left click
6. Right click
7. Charging indicator
8. ON/OFF button
9. Mode Switch Key
10. Bluetooth Pairing Key
11. USB receiver

Features

- Ergonomic vertical left-handed design
- Dual-mode connection
- 1000mAh built-in Li-ion battery

Specification

DPI	800 /1200 /1600/2400/4000
Polling rate	125 Hz
Input	5V= 500 mA

Connection

1. 2.4G

Slide the ON/OFF button(Button ⑧) to the"ON" position, then plug and play. If the connection brake off, try to rematch the code as the following steps:

1. Make sure the mouse was charged and the receiver was insert to device.
2. Slide the 2.4G/BT button (Button ⑨) to the"2.4G" position.
3. Insert the receiver to device, then press the left and right button at the same time and slide the ON/OFF button (Button ⑧) to the"ON" position. After 3s the mouse can work normally.
4. If the rebuilding failed, repeat the above steps.

2. BT

At the first time of using the BT mode, match the code as the following steps:

1. Slide the 2.4G/BT button (Button ⑨) to the "BT" position.
2. Press Bluetooth pairing key(Button (10) for 3S, and the Charging indicator (⑦)turns red and flashes.Then the "Bluetooth 4.0 Mouse" can be searched by the device.
3. Click the "Bluetooth 4.0 Mouse"then connect successfully and the indicator turn off.
4. If the rebuilding failed, repeat the above steps.

Notes:

Connecting the mouse and USB charging port with Type-C charging cable.When charging the indicate light (⑦) turn red, after full charged the light turn off.

Press the DPI Key to switch DPI among 800/1200/1600/2400/4000,the charging light flashes once twice third four and five times accordingly.Press the right, left and meddle key at the same time for 3s to turn off the light.


Debugging Tips

- Make sure the receiver is plugged in the USB port.
- Make sure the distance between mouse and device in 10m.
- Make sure the ON/OFF button are slide to"ON"position

DELUX



Documents / Resources

	<p>DELUX M618mini Wireless Vertical Mouse [pdf] User Manual</p> <p>M618mini, Vertical Mouse, M618mini Vertical Mouse, Mouse, M618mini Wireless Vertical Mouse, Wireless Vertical Mouse</p>
---	--