



DEXNOR Bluetooth Keyboard for Samsung Galaxy TAB S8 Plus User Manual

[Home](#) » [DEXNOR](#) » DEXNOR Bluetooth Keyboard for Samsung Galaxy TAB S8 Plus User Manual 

Contents

- 1 [DEXNOR Bluetooth Keyboard for Samsung Galaxy TAB S8 Plus](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [USER MANUAL](#)
- 5 [ASSEMBLING AND DISASSEMBLING INSTRUCTIONS](#)
- 6 [TRACKPAD GESTURES FOR SAMSUNG ANDROID](#)
 - 6.1 [TABLET INSTALLATION](#)
 - 6.2 [KEYBOARD CONNECTION](#)
- 7 [TROUBLESHOOTING](#)
- 8 [SPECIFICATIONS](#)
- 9 [Documents / Resources](#)
- 10 [Related Posts](#)



DEXNOR Bluetooth Keyboard for Samsung Galaxy TAB S8 Plus



Product Information


- This device should not be used in conjunction with any other antenna or transmitter.
- The device has been evaluated to meet general RF exposure requirements in portable exposure conditions without any restrictions.



Product Usage Instructions

- Do not use this device in combination with any other antenna or transmitter.
- Ensure that the device is used in portable exposure conditions only.
- Follow the safety guidelines provided in the user manual to avoid any risks associated with RF exposure.

USER MANUAL

Pairing Mode



Press and hold  and  simultaneously for 3 seconds to enter into the pairing state. Bluetooth will exit the pairing state if no connection is made within 3 minutes.




Bluetooth Connection


Go to Tablet's Settings > Bluetooth to turn it on. Find "Dexnor Keyboard" under "Available devices" and connect it.

Bluetooth Re-connection

After a successful pairing, the keyboard will automatically pair with your Tablet in 5 seconds the next time.

Charging Indicator

In Charging: 
Fully Charged: 
Low Battery: 



Auto Sleep

The keyboard backlight will automatically enter sleep mode after 30 seconds of inactivity, and the keyboard itself will also enter sleep mode after 30 minutes of inactivity. Press any key to wake up the keyboard, and it will automatically reconnect to your device.



Basic Keyboard

Go to Tablet's Settings > General management > Physical keyboard






















Trackpad Settings


On your Tablet,






















1. Go to Settings > General management > Mouse and trackpad > Adjust pointer speed
2. Go to Settings > General management > Mouse and trackpad > Wheel scrolling speed ("Slow" as shown)



A Full Row of Shortcut Keys for Easy Media Control.

	Single Press: ESC Function Press it with the Fn Key: Switch Between the Tablet and DEX Modes		Single Press: Return to Home Screen Press it with the Fn Key: F1		Single Press: Brightness - Press it with the Fn Key: F2
	Single Press: Brightness + Press it with the Fn Key: F3		Single Press: Take a Screenshot Press it with the Fn Key: F4		Single Press: Previous Track Press it with the Fn Key: F5
	Single Press: Play/Pause Press it with the Fn Key: F6		Single Press: Next Track Press it with the Fn Key: F7		Single Press: Mute Press it with the Fn Key: F8
	Single Press: Volume - Press it with the Fn Key: F9		Single Press: Volume + Press it with the Fn Key: F10		Single Press: Lock the Screen Press it with the Fn Key: F11
	Single Press: Switch Language Press it with the Fn Key: F11		Single Press: Tab Press it with the Fn Key: Switch Between Recent Apps		Single Press: Backspace Press it with the Fn Key: Enter Bluetooth Pairing Mode
	Single Press: Enter Press it with the Fn Key: Adjust 7 Backlight Colors in Cycles (Red/Green/Blue/Yellow/Cyan/Purple/White)		Single Press: Shift Press it with the Fn Key: Adjust Brightness in Cycles (Low-Medium-High-Off)		Single Press: Move Up Press it with the Fn Key: Page Up
	Single Press: Move Down Press it with the Fn Key: Page Down		Single Press: Move Left Press it with the Fn Key: Home		Single Press: Move Right Press it with the Fn Key: End
	Single Press: F Press it with the Fn Key: Search		Single Press: Win		Power Switch (Up for On/Down for Off)
	Single Press: Spacebar Press It with the Fn Key: Disable/Enable the Trackpad				

Press and hold right  key, then press the corresponding key to type the character highlighted.


	~		!		@		#		\$
	%		^		&		*		(
)		_		=		{		}
			:		<		"		>
	?								

ASSEMBLING AND DISASSEMBLING INSTRUCTIONS

Horizontal Assembling:




Horizontal Disassembling:




TRACKPAD GESTURES FOR SAMSUNG ANDROID

(Some of these gestures may not be available in the DEX system)




Press the left side to perform the left-button function.



Press the right side to perform the right-button function and access the right-click menu.



Double-tap with three fingers to show the status bar.




Move the cursor onto one App icon, press and hold the left button, then drag the App.



Tap with one finger to click.


Tap with two fingers to right-click.



Pinch or stretch out with two fingers to zoom in or out.
(Available for browser, text editor, and other software.)




Slide up or down with two fingers to scroll.




Swipe left or right with two fingers to switch between pages of the home screen.



Swipe up with three fingers to show recents.




Swipe down with three fingers to show the home screen.



Swipe left or right with three fingers to switch between open applications.



Click on the upper or right corner to show the status bar.



Left Button + Cursor:
Select Text.



On the "Recents" View:

- Move the cursor onto the app, tap/click to access to the app.
- Click on the app icon to access the app menu.
- Press and hold the left button, then swipe up the app to close it.




On the "Recents" View:
Move the cursor to the app, then press and hold the left button to enter split screen view.

TABLET INSTALLATION

- Hold your Tablet with both hands and attach it to the back cover magnetically.





- Store your Tablet into the keyboard case and fold it for on the go.





KEYBOARD CONNECTION

- Toggle the switch to ON.



- Go to the Tablet's Settings > Connections > Bluetooth (Turn It On). Click "Scan" and find "Dexnor Keyboard" under "Available devices".
- Press and hold "Fn" and "Backspace" key simultaneously for 3 seconds to enter pairing mode.



- Click "Pair" to connect.

TROUBLESHOOTING

If the keyboard doesn't work, please check:

1. If it's powered on, if not, switch it on.
2. If its battery has run out, if yes, charge it immediately.
3. If Bluetooth connection fails, turn off the keyboard and restart it after 10 seconds, and the keyboard will reconnect to your device automatically. If the problem still exists, go to Tablet Settings>Connections

>Bluetooth>Paired devices>Dexnor Keyboard>Unpair. Then reconnect the keyboard according to the previous connection steps.

4. If Bluetooth connection still fails, press  and  (or) for 3 seconds to restore factory settings. Then reconnect the keyboard.

5. Or you can restart your Tablet and then check if the keyboard can work normally.

If the keyboard still doesn't work after trying the above solutions, please try to repeat these steps. If your problems can't be solved after that, please contact the seller for help.

Friendly Reminder

1. The keyboard is built with a rechargeable polymer battery.
2. If you're not going to use the keyboard for a long time, we suggest turning it off to avoid power drain and extend its battery life.

SPECIFICATIONS

1. Bluetooth Version: Bluetooth 5.1
2. Standard Type-C Port: Supports TC charging
3. Bluetooth Range: 10 meters
4. Modulation Methods: GFSK
5. Working Voltage: 3.3-4.2 V
6. Working Current (Average Typing Speed without Backlight): 2.0 mA
7. Standby Current: 0.5 mA
8. Sleep Current: 0.01 mA
9. Charging Current: 307 mA
10. Standby Time: > 1500 h
11. Charging Time: 4 h
12. Working Current with the Brightest White Backlight: 103 mA
13. Continuous Working Time with the Brightest White Backlight: > 8 h
14. Auto-sleep Time of the Backlight: 30 s
15. Auto-sleep Time of the Keyboard: 30 min (Bluetooth will disconnect during deep sleep mode. Any key can be pressed to wake it up.)
16. Lithium Battery Capacity: 800 mAh
17. Continuous Working Time Without Backlight: > 320 h
18. Life Cycle of the Lithium Battery: 300 times
19. Size of the Lithium Battery: 3.3 * 34 * 76 mm
20. Bluetooth Pairing Name: Dexnor Keyboard

COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.
This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

Documents / Resources

	DEXNOR Bluetooth Keyboard for Samsung Galaxy TAB S8 Plus [pdf] User Manual 2BA3T-DK001, 2BA3TDK001, dk001, Samsung Galaxy TAB S8 Plus, Samsung Galaxy TAB S7 Plus, Samsung Galaxy TAB S7 FE, Bluetooth Keyboard for Samsung Galaxy TAB S8 Plus, Bluetooth Keyboard, Keyboard
---	---