

DHgate.com

**DHgate
PLUSE7
Bluetooth Mini
Speaker**



DHgate PLUSE7 Bluetooth Mini Speaker Instruction Manual

[Home](#) » [DHgate](#) » DHgate PLUSE7 Bluetooth Mini Speaker Instruction Manual 

Contents

- 1 DHgate PLUSE7 Bluetooth Mini Speaker
- 2 Product Specifications
- 3 Product Functional Features
- 4 Performance parameter description
- 5 Function/Key Description
- 6 Bluetooth usage instructions
- 7 Product warranty card
- 8 Matters Needing Attention
- 9 Frequently Asked Questions
- 10 Documents / Resources
 - 10.1 References

DHgate.com

DHgate PLUSE7 Bluetooth Mini Speaker



Product Specifications

- Bluetooth version: 5.3
- Wireless transmission distance: 10 meters (accessible)
- Signal to noise ratio: 85DB
- Horn specification: 4Ω 15W * 1
- Charging voltage: USB-DC5V

Please carefully read and properly store this manual








Product Functional Features

1. This product has a fashionable appearance, is exquisite and compact, and is easy to carry during travel and sports,
2. Select high-performance Bluetooth modules for smoother use;
3. Equipped with TF card, supporting decoding of music formats such as MP3,
4. Efficient digital power amplifier, green and environmentally friendly;
5. Built in 5000 mA rechargeable 18650 lithium battery;
6. Equipped with high-quality speakers, the sound quality is pure and beautiful;
7. Unique resonant structure, outstanding bass.

Performance parameter description

- Bluetooth version: 5.3
- Wireless transmission distance: 10 meters (accessible) Signal to noise ratio: $\geq 85\text{DB}$
- Horn specification: 4Q 15W * 1
- Charging voltage: USB-DC5V

Function/Key Description

-  Long press power on/off, short press play/pause
-  Light mode conversion
-  Function mode conversion (AUX, TF, USB drive, Bluetooth)
-  Long press one song, short press the volume to increase
-  Long press the previous song, short press the volume to decrease
-  Bluetooth indicator light, charging indicator light
-  TYPE-C charging input AUX/TF card, USB drive input

Bluetooth usage instructions

Turn on or press the mode key to switch to Bluetooth mode, with a synchronized ringtone prompt; The machine will prompt for Bluetooth status, and after pairing with other devices and successfully connecting, Bluetooth listening to music can be achieved.

Instructions for card reading/USB usage:

Insert the TF card/USB, and the machine will automatically recognize and play the music from the TF card. At this time, playback control can be carried out through keys such as Previous Song, Next Song, Play/Pause, etc.

Instructions for using voiceover input:

Insert the audio adapter cable into the AUX port of the machine and connect it to the headphone output port of the phone or computer. Press the button to switch to external audio mode. Open the audio software on your phone or computer to play music.

Product warranty card

This card is a product warranty certificate, please keep it properly

This card is a product warranty certificate, please keep it properly

Product name:	Product model:
Date of purchase:	Customer name:
contact information:	

Product maintenance record

date	Adverse phenomenon	Solution



Matters Needing Attention

1. If the machine experiences smoke or other abnormal phenomena, please contact the dealer or contact our company for after-sales treatment.
2. If the interior of the machine is exposed to rain or moisture, please place the machine in a ventilated area to dry.
3. Do not use high temperature to bake this machine, as it may burn or cause internal components to fail.
4. This product must not be exposed to environments such as sunlight, baking, or similar overheating.
5. Do not throw to avoid falling and damaging.
6. If the battery is not replaced properly, there is a risk of explosion. Only batteries of the same type or effective type can be replaced.
7. Batteries (battery packs or combination batteries) should not be exposed to environments such as sunlight, fire, or similar overheating.

Note: Our company is constantly committed to improving the quality and performance of our products. The technology and design of our products are subject to updates without prior notice. We reserve the right to continuously improve our products, and the functionality of our products is subject to the actual product!

Frequently Asked Questions

Q: How do I charge the device?

A: Use a USB-DC5V charging cable to charge the device.


Q: Can I use the device while it's charging?

A: Yes, you can use the device while it's charging.

Q: How do I know when the device is fully charged?

A: The charging indicator light will turn off when the device is fully charged.

Documents / Resources

	DHgate PLUSE7 Bluetooth Mini Speaker [pdf] Instruction Manual 2BH5K-PLUSE7, 2BH5KPLUSE7, PLUSE7 Bluetooth Mini Speaker, PLUSE7, Bluetooth Mini Speaker, Mini Speaker, Speaker
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.