



DIGDIY D10 Active Noise Cancelling Bluetooth Earbuds User Guide

[Home](#) » [DIGDIY](#) » DIGDIY D10 Active Noise Cancelling Bluetooth Earbuds User Guide



Contents [[hide](#)]

[1 QUICK OPERATION GUIDE](#)

[2 ANC Siri](#)

[2.1 1 –](#)

[2.2 2 –](#)

[2.3 3-](#)

[2.4 4-](#)

[2.5 6-](#)


[2.6 7-](#)

[2.7 8-](#)

[2.8 9-](#)

[3 Documents / Resources](#)




[4 Related Posts](#)




QUICK OPERATION GUIDE


DIGDIY **D10**








2- 




3- 

ON

OFF




4- 





Valid in dual mode.

5- Siri



6-




7- RESET



Make sure the charging case is open, hold the MFB 5s until the LED indicators blink 10 times.



8- 



L

R

9- 

When the charging case needs a boost, simply place it on a wireless charger.



www.digdiytech.com

Register to extend warranty

Email us: support@digdiytech.com

Documents / Resources



[DIGDIY D10 Active Noise Cancelling Bluetooth Earbuds](#) [pdf] User Guide
D10, Active Noise Cancelling Bluetooth Earphone, D10 Active Noise Cancelling Bluetooth Earphone, Noise Cancelling Bluetooth Earphone, D10 Wireless Earbuds