

digital basics Air Exec Keyboard Case for iPad 10 Gen User Guide

Contents

[1 Air Exec Keyboard Case for iPad 10 Gen](#)

[2 Product Information](#)

[2.1 Package Contents:](#)

[2.2 Safety Instructions:](#)

[3 Product Usage Instructions](#)

[3.1 Preparation for Use:](#)

[3.2 Setup Keyboard for Use:](#)

[3.3 Getting to Know Your Keyboard:](#)

[3.4 Reset Pairing:](#)

[3.5 Keyboard Shortcuts:](#)

[3.6 Multimedia Function Instructions and Switches:](#)

[3.7 Documents / Resources](#)

Air Exec Keyboard Case for iPad 10 Gen

Product Information

Congratulations on your purchase of this keyboard case. This product is designed to provide a convenient and efficient typing experience for your device. Please read the following instructions to ensure proper care, maintenance, and usage of the product.

Package Contents:

- Keyboard case
- Micro USB cable
- User manual

Safety Instructions:

Before using the product, please take note of the following safety instructions:

- While cleaning the product, always unplug it from the power supply.
- Use only a dry soft cloth to wipe the product. Avoid water or any other liquids.
- If not using the product for an extended period of time, unplug

it.

- Avoid using harsh cleansers or detergents.

Product Usage Instructions

Preparation for Use:

Follow these steps to prepare the keyboard case for use:

1. Unpack the accessories carefully, and keep the box and packing materials for future storage.

Setup Keyboard for Use:

Follow the steps below to set up the keyboard:

1. Place the keyboard case in the stationary position as shown in **Figure A**.
2. To adjust the operating position angle, refer to **Figure B**.
3. To charge the keyboard case, follow these steps as shown in **Figure C**:
 - Connect the included micro USB cable to a powered USB hub, USB port on your computer, or any USB power adapter.
 - While charging, the LED indicator light will be illuminated in red.
 - When fully charged, the LED indicator will not be illuminated. When charging is required, the LED indicator will flash red.

Getting to Know Your Keyboard:

Familiarize yourself with the keyboard features:

- **CAPS Indicator Light:** When lit blue, indicates UPPERCASE mode. If not lit, you are typing in lowercase mode.
- **Charging Indicator Light:** When lit red, indicates the keyboard is charging.
- **Power Indicator Light:** When flashing, indicates the need to charge the keyboard. When first powered on, the light will stay lit for 4 seconds to show power but will turn off to save energy.

Reset Pairing:

If you need to reset the pairing of your device with the keyboard case, follow these steps:

1. Tap on the “More Information” icon on your device’s screen.
2. Select “Forget This Device” on your device’s screen.

Keyboard Shortcuts:

Use the following keyboard shortcuts for different system functions:

Button Icon	Android System Function	Windows System Function	IOS System Function
Main page	Main page	Main page	Search
Select all Copy	Select all Copy	Select all Copy	Paste
Cut	Cut	Cut	Previous Track Play/Pause
Next Track	Next Track	Next Track	Volume –
Volume +	Volume +	Volume +	Brightness Brightness +
Brightness Brightness +	Brightness Brightness +	Brightness Brightness +	Lock screen Virtual keyboard
Lock trackpad Language switch	Lock trackpad Language switch	Lock trackpad Language switch	–

Multimedia Function Instructions and Switches:

To access multimedia functions, press the corresponding buttons directly for Android/Windows/IOS systems. For Windows system, press Fn+F1~F12 to achieve system functions. To shift between different systems, press Fn and Q (Android), W (Windows), or E (IOS) keys together.

Follow these instructions and guidelines to maximize your experience with the keyboard case. If you have any further questions or need assistance, please refer to the user manual or contact our customer support.

[View Fullscreen](#)

Package contents:

1x Case with built-in Bluetooth® keyboard 1x Micro USB charging cable * DOES NOT INCLUDE Apple iPad®
Safety instructions

Congratulations on your purchase of this keyboard case. To get the most from your product, please take a few minutes to read these instructions.

· Always follow basic safety precautions

1. Care and maintenance instructions

While cleaning the product, you should first unplug them from the power supply (where applicable) Use only a dry soft cloth to wipe the product. Never allow water or any other liquids to get inside the product while cleaning. Unplug the product if you are not using it for an extended period of time. Avoid using harsh cleansers or detergents.

2. Preparation for use

Unpack the accessories carefully. We recommend that you save the box and packing materials in case you wish to store the products.

How to setup keyboard for use

Place your iPad® inside of the case making sure you align the camera hole on the case with the camera on the back of the iPad® and clip into place. The keyboard case has a stationary position and an operating position. Stationary position (Figure A) and operating position (Figure B). The stationary position is for when you are transporting and storing the iPad® and the operating position is designed to provide the user with a preferred

viewing angle while you are typing.

FIGURE A: STATIONARY POSITION

FIGURE B: OPERATING POSITION ANGLE

Stationary position to operating position

The case will be moved from the stationary position to the operating position by opening the keyboard case with the iPad® case on top and the keyboard on the bottom (Figure C). The top of the keyboard should be aligned with the bottom of the case. You will feel the magnets hold the keyboard in place, then angle the iPad® case so that it rests on top of the keyboard case. This can be adjusted based on your preferred viewing angle. (Figure B)

FIGURE C:

Charging

It is critically important to make sure both your iPad® and keyboard case are fully charged before use. To charge your Keyboard Case; 1. Locate the micro USB slot that is on the (right) side of the keyboard case (parallel to the power switch). 2. Use the included micro USB cable and plug it into a powered USB hub, USB port on your computer or any USB power adapter (not included) 3. While the keyboard is being charged, the LED indicator light will be illuminated

with a RED color. When the keyboard case is fully charged, the LED indicator will not be illuminated. When the keyboard case requires charging, the LED indicator will flash RED.

Getting to know your keyboard

1. CAPS indicator light; when lit blue, will show you are in UPPERCASE mode. If not lit, you are typing in lowercase mode.
2. Bluetooth® indicator light; when connecting a blue light will flash. Once connected, the light will stop flashing.
3. Charging Indicator Light: When lit red, indicates keyboard is charging.
4. Power Indicator Light: when flashing, indicates you need to charge the keyboard. When first powered on, the light will stay lit for 4 seconds to show power but will turn off to save energy.

Connecting your keyboard with your iPad® for the first time

Note: This keyboard is designed with shortcut keys (the keys that have blue color writing/icons) that are only optimized for the Apple iOS iPad® operating system). This keyboard will operate on other Bluetooth® enabled devices however the aforementioned shortcut keys will not function according to the table outlined below in this manual as this keyboard is designed for use with Apple® mobile devices. 1. Turn on your iPad® and go to your settings. In settings, select Bluetooth® and make sure you have Bluetooth® enabled (in the ON position). 2. Turn on the power button on your keyboard case by moving the toggle switch to the right. Note, even though the power LED indicator will illuminate in blue color and will turn off after 4 seconds; the keyboard is still on and will remain on until you toggle the power switch to the OFF position. 3. Press and hold down the “Fn+Connect” button (+) for 3 seconds. The LED indicator over the Bluetooth® icon will flash in a blue color. 4. In Bluetooth® settings on your iPad®, you will see a new device “Bluetooth® keyboard” appear. Select this and it will begin to pair. 5. You will now see the word “Connected” next to the “Bluetooth® keyboard” in your Bluetooth® setting. You are now paired. Note: If you lose the connection (such as when your keyboard case depletes battery and needs to be recharged); to reconnect, simply find the Bluetooth® keyboard in your Bluetooth® settings, select “Not connected” and your iPad® will search for the keyboard case. Make certain the keyboard case is powered on. The status of your Keyboard in Bluetooth® settings should change to “Connected”.

How to reset pairing

If your iPad® displays “Connection Unsuccessful”, make certain the Bluetooth® keyboard is powered on and in range (within approximately 30 feet) of the iPad®. If after checking the above and it will still not pair, simply delete the profile by selecting the Bluetooth® keyboard, then select “Delete This Device” and repeat the pairing process again.

Tap on the More Information icon your iPad screen

Tap on Forget This Device on your iPad screen

* Repeat steps 1-6 to connect the keyboard to your iPad®

Keyboard shortcuts

The blue icons on the keys of the keyboard, indicate that you will need to hold down the “Fn” button on the bottom left of the keyboard at the same time as selecting the shortcut you would like. the “Fn” button.

Button icon

+ + +

Android System function Windows System function IOS System function

Main page

Main page

Main page

Search

Search

Search

Select all Copy

Select all Copy

Select all Copy

Paste

Paste

Paste

Cut

Cut

Cut

Previous Track Play/Pause

Previous Track Play/Pause

Previous Track Play/Pause

Next Track

Next Track

Next Track

Volume –

Volume –

Volume –

Volume +

Volume +

Volume +

Brightness Brightness +

Brightness Brightness +

Brightness Brightness +

Lock screen Virtual keyboard

Lock screen Virtual keyboard

Lock screen Virtual keyboard

Lock trackpad Language switch

Lock trackpad Language switch

Lock trackpad Language switch

Button icon + + + +

Android System function Windows System function

Home page

Home page

Page up Page down End page

Page up Page down End page

IOS System function Home page
Page up Page down End page

Multimedia Function Instructions and Switches

Android/Windows/IOS, press directly to achieve the multimedia function; Win system, press Fn+F1~F12 to achieve the system function. NOTE: Press Fn and Q(Android), W(Windows), E(IOS) keys together to shift between Android/Windows or IOS, systems after connected successfully with a corresponding device.

Energy saver/sleep mode

The keyboard will go into sleep mode automatically when it is inactive for 15 minutes. To wake, simply press any key on the keyboard and wait for 3 seconds. The keyboard will turn back on

Trackpad Gesture Function Description

Note: Please upgrade iPad to iOS version 13.4.1 for best experience

Gestures Android Windows

IOS

Gestures Android Windows

IOS

Move cursor Move cursor Move cursor

Slide finger

Move up with

/

3 fingers

Switch to recent program

Switch to recent program

Open with 3 fingers

Select

Select

Select

Switch back to Switch back to Switch back to Move down home screen home screen home screen with 3 fingers

Click with 2 fingers

/

Move Right button

Move Right

Switch to

Switch to

Switch to

button

Move left with activity center activity center activity center

h3ofilndgers and

Click with

/

3 fingers

Search

/

Switch to

Switch to

Switch to

Move left with activity center activity center activity center

3 fingers and

hold down

Quick click

/

Select left click target drag

/

aDnodubdlreagclick

Move fingers caltoasnegtloeg, ether

/

Scroll up or

Swipe two fingers up or down

Swipe two fingers up or down

Swipe two fingers up or down

afonrdzoaowmayinfor zoom out

down

If you have any confusions, please feel free to contact us for technical support.

Zoom in or out

Zoom in or out

Operating position to stationary position

Once you are finished using your keyboard case, it must be closed properly to avoid damage to your keyboard or iPad®. Make sure the bottom of the iPad® case while in operating mode is positioned on the top of the keyboard. Next, while closing the keyboard case, make sure the top of the iPad® case is evenly aligned with the bottom of the keyboard. Once closed completely, the two magnets on the case strap will hold the case together in stationary position until you are ready to use the keyboard and/or iPad® again. (See figure A & B)

Specifications

Bluetooth® 4.2 interface Operating Distance-Up to approx. 30 feet Operating Voltage: 3.0-4.2V Operating Current: <2.5mA Charging Time: (approx.) 2-4 hours Battery Life: (approx.) 8-10 hours Battery Capacity: 180mAh Operating Temp: 14°F-131°F

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Support

If you are having problems with your product, please contact customer support before contacting your retailer.

Digital Gadgets

866-843-6460

Digital Gadgets Limited Warranty Statement

Digital Gadgets warrants this product against defects in workmanship and material for a period of 12 months from the original date of purchase. If the product fails during normal and proper use within the warranty period, Digital Gadgets will repair or replace any products or parts determined to be defective in workmanship or material at its option. All components repaired or replaced by Digital Gadgets' service will be under warranty for the remaining warranty period.

This Limited Warranty covers only the accessory components packaged with this product. This Limited Warranty does not include failure caused by improper installation, operation, cleaning or maintenance, accident, damage caused by extreme temperature, humidity or extreme electrical stress, misuse, abuse, modifications to the product, software faults, normal wear and tear or any other event, act, default or omission outside of Digital Gadgets' control or if the unit casing has been opened. Any attempt to repair this product will void your limited

warranty.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.


To obtain warranty service, please contact Digital Gadgets for specific instructions at the telephone number below. Dated, documented proof of the original purchase is required.

Digital Gadgets customer service representatives are available by calling 866-843-6460 Apple® and iPad® are trademarks of Apple Inc., registered in the U.S. and other countries.

Bluetooth® is a registered trademark of Bluetooth SIG Inc. The Bluetooth® word mark and logos are owned by the Bluetooth SIG Inc..

All other trademarks and trade names are owned by their respective owners. ©2023 by Digital Gadgets, LLC
MADE IN CHINA

Documents / Resources

	<p>digital basics Air Exec Keyboard Case for iPad 10 Gen [pdf] User Guide</p> <p>X2K-BAIPTHK109, X2KBAIPTHK109, baipthk109, Air Exec Keyboard Case for iPad 10 Gen, Air Exec, Keyboard Case for iPad 10 Gen, Air Exec Keyboard Case, Keyboard Case, Case</p>
---	--