



Home » DIGITAL WATCHDOG » Digital Watchdog DWC-XSTD05Bi Next Generation Video

Analytics User Guide

Digital Watchdog DWC-XSTD05Bi Next Generation Video Analytics User Guide

June 3, 2025

Contents [hide]

- 1 DWC-XSTD05Bi Next Generation Video Analytics
- 2 Specifications:
- 3 Product Usage Instructions:
 - 3.1 Initial Setup:
 - 3.2 Safety Guidelines:
 - 3.3 Cleaning and Maintenance:
- 4 FAQ:
 - 4.1 Q: What should I do if the camera does not operate normally?
 - 4.2 Q: How do I change the default login password?
 - 4.3 Documents / Resources
 - 4.3.1 References

DWC-XSTD05Bi Next Generation Video Analytics

"

Specifications:

Model: DWC-XSTD05Bi (fixed lens) / DWC-XSTD05Mi (vari-focal

lens)

- Login Information: Default admin | admin
- Mounting Template Included
- Tools Included: Hexagonal wrench 2.0, Screws, Plastic, Star Wrench (T10), Moisture Absorber

Product Usage Instructions:

Initial Setup:

- 1. Visit http://www.digital-watchdog.com/resources
- 2. Search for your product by entering the part number in the search bar
- 3. Download all supported materials and manuals

Safety Guidelines:

- Ensure the camera is firmly fixed when mounted on a wall or ceiling
- Use only the specified adapter to avoid fire, electrical shock, or damage
- 3. Check power supply voltage before use to prevent accidents

Cleaning and Maintenance:

- Do not spray water directly onto the product while cleaning
- Use proper safety gear when handling the product

FAQ:

Q: What should I do if the camera does not operate

normally?

A: Contact the nearest service center for assistance. Never attempt to disassemble or modify the product yourself.

Q: How do I change the default login password?

A: When logging in for the first time, follow the on-screen instructions to set a new password.

"

View Fullscreen



When logging into the camera for the first time, you must setup a new password. You can set the new password using the

DW® IP FinderTM software or directly from the camera's browser menu.

Quick Setup and Download Guide

Mounting Template

Hexagonal wrench 2.0

Waterproof Cap and Rubber Rings (Black: ø0.15" (ø4mm), White: ø0.19" (ø5mm))

Screws and 1 **Plastic** Anchors 2pcs 1 Star Wrench (T10) 1 Moisture Absorber (Recommended) 1 set 1 **ESI TOP DESI** TOP DESI Т 1 1 set NOTE: Download all your support materials and tools in one place

WHAT'S IN THE BOX

1. Go to: http://www.digital-watchdog.com/resources 2. Search your product by entering the part number in the `Search by Product' search

bar. Results for applicable part numbers will populate automatically based on the part number you enter. 3. Click 'Search'. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.

Attention: This document is intended to serve as a guick reference for the initial set-up. It is recommended that the user read the entire instruction manual for complete and proper installation and usage.

SAFETY AND WARNING INFORMATION

Read through this Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. See the user manual for more information on the proper installation, use and care of the product. These instructions are intended to ensure that users can use the product correctly to avoid danger or property loss. Warnings: Serious injury or death may occur if any of the warnings are neglected. Cautions: Injury or equipment damage may occur if any of the cautions are neglected. WARNING 1. In the use of the product, you must be strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed. 2. Be sure to use only the standard adapter specified in the specification sheet. Using

any other adapter could

cause fire, electrical shock, or damage to the product. 3. Make sure the power supply voltage is correct before using the camera. 4. Incorrectly connecting the power supply or replacing the battery may cause an explosion, fire, electric shock, or damage to the product. 5. Do not connect multiple cameras to a single adapter.

Exceeding the capacity may cause excessive heat

generation or fire. 6. Securely plug the power cord into the power source. An insecure connection may cause a fire. 7. When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury. 8. Do not install in a location subject to elevated temperature, low temperature, or high humidity. Doing so may cause fire or electric shock. 9. Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top

of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects. 10. Do not install in humid, dusty, or sooty locations. Doing so may cause fire or electric shock. 11. Do not install near any heat sources such as radiators, heat registers, or other products (including amplifiers)

that produce heat. 12. Keep out of direct sunlight and heat radiation sources. It may cause a fire. 13. If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the

power source and contact the service center. Continued use in such a condition may cause fire or electric shock. 14. If this product does not operate normally, contact the nearest service center. Never disassemble or change this

product in any way. 15. When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or

electric shock. CAUTION 1. Use proper safety gear when installing and wiring the product. 2. Do not drop objects on the product or apply strong shock to it. Keep away from a location subject to excessive

vibration or magnetic interference. 3. Do not use this product near water. 4. The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall

be placed on the product. 5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the

image sensor. 6. The Main plug is used as a disconnect device and shall stay readily operable at any time. 7. Remove the power adapter from the outlet when then there is lightning. Neglecting to do so may cause fire or

damage to the product. 8. Do not block any ventilation openings. Install following the manufacturer's instructions. 9. A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one

wider than the other. A grounding-type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.

10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product. 11. If any laser equipment is used near the product, make sure the surface of the sensor is not exposed to the laser beam as that may damage the sensor module. 12. If you want to move the already installed product, be sure to turn off the power and then move or reinstall it. 13. Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user. 14. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt. 15. Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device

will not be used for a long time, please cover the lens cap to protect the device from dirt. 16. Use only attachments/accessories specified by the manufacturer. 17. Always use hardware (e.g. screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount. 18. Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. 19. Unplug this product when a cart is used. Use caution when moving the cart/product combination to avoid injury from tip-over. 20. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

STEP 1 PREPARING TO MOUNT THE CAMERA

- 1. Install the Dessicant Pack (moisture absorber):
- · Remove the Dessicant Pack from its shipping packaging. Fold the moisture absorber pack diagonally along the dotted line, as shown in the diagram below.
- · Open the camera's control panel on the side of the camera using the star wrench included with the camera.
- t
- C

\cdot Remove the Dessicant Pack used for shipping and place the new Dessicant Pack in
the location shown in the illustration below.
· Close the camera control panel tightly. When closing the control panel, ensure no
cables are caught or disconnected.
ESI
TOP DESI
TOF DESI
TOP DESI
T
Ealding
Folding
in
half

NOTE: The camera will generate enough heat to dry moisture during normal operation.

In cases where the camera experiences a moisture issue, keep the moisture absorber in

the camera.

WARNING: Install the moisture absorber when mounting the camera to prevent

performance issues and damage to the camera.

2. Mark and drill the necessary holes in the wall or ceiling using the mounting template

sheet or the camera itself.

STEP 2 POWERING THE CAMERA

Pass the wires through and make all necessary connections.

Use a PoE Injector (Sold

separately) to connect data and

power to the camera using a

single Ethernet cable.

OR

Use a non-PoE Switch to connect data using an Ethernet cable and use a power adapter

to power the camera.

Power information

Power requirements DC12V, PoE (Adapter not included)

Power consumption

DWC-XSTD05Bi: DC: max 7.5W, 625mA, PoE: max 9.5W, 197mA DWC-XSTD05Mi:

DC: max 8.5W, 708mA, PoE: max 11W, 229mA

Maximum distance 328' (100m)

Connector

RJ45

WATERPROOF CAP INSTALLATION

The waterproof cap set comes with two rubber rings. Use the rubber ring best sized for your network cable's diameter.

NOTE: Cables with ø4.5mm to ø5.5mm thickness should use the black rubber ring. Cables over ø5.5mm in thickness should use the white rubber ring.

NOTE: Make sure the o-ring d is in place between c and e to prevent moisture damage. In extreme environments, use an outdoor-rated electrical tape.

NOTE: Unused cables should be sealed with electric tape.

STEP 3 INSTALLING THE CAMERA

1. Secure the camera to the mounting surface using the included screws. 2. Use the rubber plug on the side of the camera as a cable guide to prevent cables from getting caught between the camera and the mounting surface. Rubber plug

3. Adjust the camera's view and position by loosening the rotation screws using the

hexagonal wrench.

Rotation 360°

Panning 360°

Tilting 87°

NOTE: When setting up the DWC-XSTD05Mi camera for the first time, use the CALIBRATE button on the camera's web GUI to calibrate the camera's lens before operation.

4.Remove the protective film from the lens cover. Softly wipe the lens cover with lens tissue or a microfiber cloth with ethanol to remove any dust or smudges left from the installation process.

Reset Button Resetting the camera: Press the reset button for five (5) seconds to initiate a camera-wide reset of all the settings, including network settings.

Mounting template

Protective film

STEP 4 CABLING

DI (+) DI (-) DO (-) DO (+)

WHITE YELLOW SKY BLUE GRAY + DOT

1. Power – Connect the camera to a power supply (see STEP 2). 2. Network – Connect the camera to the network via a PoE switch (see STEP 2). 3. Audio out – Connect external audio devices such as a speaker to the camera. 4. Alarm out – Connect alarm devices such as lights, sirens or door locks. See the table to the right for color cables. 5. Alarm In – Connect sensor or alarm input devices. See the table to the right for color cables.

STEP 5 MANAGING THE SD CARD (OPTIONAL)

- 1. Open the camera's control panel on the side of the camera using the star wrench included with the camera.
- 2. Insert class 10 SD/SDHC/SDXC card into the SD card slot by pressing the SD card until it clicks.
- 3. Press the card inward until it clicks to release from the card slot, then remove the card.

NOTE: Maximum SD Card size supported: Up to 1TB micro SD / FAT32. When inserting the SD card into the card slot, the SD card's contacts should be facing upward, as shown in the diagram.

SD Card Slot

STEP 6 DW® IP FINDERTM

- 1. Download and install the DW IP Finder from the DW website at: http://www.digital-watchdog.com
- 2. Open the DW IP Finder and click `Scan Devices' to find the camera on the network.
- 3. A password must be set when connecting to the camera for the first time. a. Check

the box next to the camera. b. Click "Bulk Password Assign" on the left. c. Enter admin/admin for the current username and password. Enter a new username and password to the right. Password must have at least eight (8) characters and at least four (4) combinations of uppercase and lowercase letters, numbers and special characters. Passwords cannot contain the user ID. d. Click "change" to apply all changes.

STEP 7 WEB VIEWER

The GUI display may differ by camera models.

1. Find the camera using the DW IP Finder. 2. Double-click on the camera's view in the results table. 3. Press the `View Camera Website'. 4. Enter the camera's username and password you setup in the DW IP

Finder. If you did not setup a new username and password, a message will direct you to setup a new password for the camera to view the video.

NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: This products is covered by one or more claims of the HEVC Patents listed at patentlist.accessadvance.com.

Tel: +1 <u>866-446-3595</u> / <u>813-888-9555</u> Technical Support Hours: 9:00AM 8:00PM EST, Monday through Friday

digital-watchdog.com

Rev: 02/25

Copyright © Digital Watchdog. All rights reserved. Specifications and pricing are subject to change without notice.

Documents / Resources



Digital Watchdog DWC-XSTD05Bi Next Generation Video Analytics [pdf]

User Guide

DWC-XSTD05Bi, DWC-XSTD05Mi, DWC-XSTD05Bi Next Generation Video Analytics, DWC-XSTD05Bi, Next Generation Video Analytics, Video Analytics, Analytics

References
User Manual
■ DIGITAL WATCHDOG Analytics, DIGITAL WATCHDOG, DWC-XSTD05Bi, DWC-XSTD05Bi Next Generation Video Analytics, DWC-XSTD05Mi, Next Generation Video Analytics, Video Analytics
Leave a comment
Your email address will not be published. Required fields are marked*
Comment *
Name
Email
Website
☐ Save my name, email, and website in this browser for the next time I comment.
Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.