



DIGITECH QM-3410 Boom Box Amplifier with Bluetooth User Manual

[Home](#) » [Digitech](#) » DIGITECH QM-3410 Boom Box Amplifier with Bluetooth User Manual 



**QM-3410 Boom Box
Amplifier with Bluetooth
User Manual**

Contents

- [1 QM-3410 Boom Box Amplifier with Bluetooth](#)
- [2 FEATURES](#)
- [3 CONTROL PANEL INPUTS & FUNCTIONS](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)

QM-3410 Boom Box Amplifier with Bluetooth



**Boom Box Amplifier
with Bluetooth
QM-3410**

Please read this user manual carefully before using. And keep this user manual for future use.




There is high voltage inside, do not open.
If malfunction occurs, please contact the after sell service centre.

FEATURES


1. MP3 Player
2. USB Reader (Max 32GB)
3. SD Card Reader (Max 32GB)
4. Bluetooth Connection
5. FM Radio
6. Line In
7. Full Function Remote Control
8. DC Power Supply Range 12V

9. AC Power Supply Range 100-240V
10. Accessories: AC Cable, DC Cable, Remote Control and User Manual

CONTROL PANEL INPUTS & FUNCTIONS



1. Line In
2. FM Radio Antenna
3. USB Reader
4. SD Card Reader
5. IR IN (Remote Control Antenna Socket)(Antenna is not included).
6. Previous track in Music/Bluetooth mode; previous channel in FM mode.
7. Play/Pause, Mode, Search Key
Play/Pause Key, in Music/Bluetooth mode, short press it to play/pause the playing;
Mode Key: Long press it to switch different modes: Bluetooth, FM, Music, Line In
Search Key: In FM mode, press it shortly to start to search the radio channels. Press it again shortly to stop searching. The Channels can be stored automatically.
8. Next track in Music/Bluetooth mode; next channel in FM mode
9. Volume Adjuster
10. Treble Adjuster
11. Bass Adjuster
12. DC Input Socket (12V)
13. AC Input Socket (100-240V)
14. Working Indicator LED
15. Power Switch
16. IR: Remote Control Signal Receiver Window



1. Standby Key
2. Repeat Key
3. CH
4. CH+
5. Previous
6. Next

7. Volume
8. Volume+
9. Numerical Keys
10. Mode Key
11. EQ
12. Play/Pause/Search




Distributed by:
TechBrands by Elects Distribution Pty. Ltd.
320 Victoria Rd, Rydal mere
NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com
Made in China
<https://manual-hub.com/>



[DIGITECH QM-3410 Boom Box Amplifier with Bluetooth](#) [pdf] User Manual
QM-3410 Boom Box Amplifier with Bluetooth, QM-3410, Boom Box Amplifier with Bluetooth, Amplifier with Bluetooth, Bluetooth

References

- [E Electus Distribution - Home](#)
-  [Manual-Hub.com - Free PDF manuals!](#)
- [User Manual](#)

Manuals+. [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.