

DIGITUS DK-1612-010 Patch Cord User Guide

Home » DIGITUS » DIGITUS DK-1612-010 Patch Cord User Guide 1

Contents

- 1 DIGITUS DK-1612-010 Patch Cord
- **2 Product Information**
- 3 Specifications
- **4 Safety Notes**
- **5 Installation Steps**
- **6 Maintenance and Care**
- 7 FAQ
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



DIGITUS DK-1612-010 Patch Cord



Product Information

Specifications

Product Name: DIGITUS CAT 6 U/UTP patch cord

Part Number: DK-1612-010

• EAN: 4016032371861

Cable Type: CAT 6, U/UTP

· Jacket Material: PVC

• Conductor Type: AWG 26/7

• Length: 1 meter

Color: Grey

CAT 6, U-UTP patch cord, PVC AWG 26/7, length 1 m, color grey

Safety Notes

- When plugging and unplugging the cable, only grasp the plug and do not pull directly on the cable.
- Cables must not be kinked sharply or bent at tight angles, as this can damage the inner wires and lead to failures.
- Ensure that the cables are not under tensile load, as this can damage the insulation and the wires inside the cable.
- Ensure that cables are not laid in areas where they can be easily damaged mechanically.
- Cables should not be used in environments with extremely high or very low temperatures. Observe the product information on the maximum operating temperature of the cable
- Check cables regularly for visible damage such as cracks, kinks or signs of wear. Defective cables should be replaced immediately to avoid failures, short circuits or even electric shocks.

Installation Steps

- 1. Identify the devices you want to connect using the patch cord.
- 2. Insert one end of the patch cord into the appropriate port of the first device.
- 3. Connect the other end of the patch cord to the corresponding port on the second device.
- 4. Ensure a secure connection on both ends.
- 5. Avoid placing strain on the patch cord during use.

Maintenance and Care

To maintain the performance and longevity of your patch cord:

- Regularly inspect the patch cord for any signs of wear or damage.
- Clean connectors periodically to ensure good signal transmission.
- Avoid pulling on the cable when disconnecting devices.
- Store the patch cord properly when not in use to prevent tangling or bending.

EU responsible person

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH Auf dem Schüffel 3 Lüdenscheid, Germany

https://www.assmann.com Email: info@assmann.com

FAQ

Q: How do I know if my patch cord needs replacement?

A: If you notice any physical damage, connectivity issues, or inconsistent performance, it is advisable to replace the patch cord immediately.

Q: Can I use this patch cord outdoors?

A: It is recommended to use the patch cord indoors to prevent exposure to harsh environmental conditions that can affect its performance.

Documents / Resources



DIGITUS DK-1612-010 Patch Cord [pdf] User Guide DK-1612-010, DK-1612-010 Patch Cord, DK-1612-010, Patch Cord, Cord

References

- A ASSMANN Electronic GmbH | Deutschland
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.