

DIGIVIEW 7197-49GY Stone Desktop Bluetooth Speaker Instruction Manual

Home » DIGIVIEW » DIGIVIEW 7197-49GY Stone Desktop Bluetooth Speaker Instruction Manual



Contents


- 1 DIGIVIEW 7197-49GY Stone Desktop Bluetooth **Speaker**
- **2 Functions**
- 3 Instructions:
- **4 SAFETY PRECAUTIONS**
- **5 FCC STATEMENT**
- 6 Documents / Resources
- **7 Related Posts**



DIGIVIEW 7197-49GY Stone Desktop Bluetooth Speaker



Functions



- 1. Micro USB Port
- 2. LED Indicator
- 3. 3.5mm Aux input port
- 4. ON/OFF Switch

What's Included

- 1 x Cement Desktop Bluetooth Speaker
- 1 x USB to Micro-USB Gable
- 1 x Instruction Manual

Tech Specifications

· Pairing Name: "Set in Stone BT speaker"

Input: 5V/1A

· Playback time at max volume: 6hrs

· Charge time: 4hrs

Instructions:

1. Charging Iha Bluetooth Speaker

- 1. Connect the provided charging cable to a power source and to the Micro USB input pcrt(1) on the speaker.
- 2. The charging LED indicator(2) will glow RED when charging and will tum off when fully charged.

2. Bluatooth0 Setup:

- 1. Tum ON/OFF switch(4) to the ON position, LED indicator will flash BLUE and tone.
- 2. Tum on the Bluetooth function on a mobile device, Select ~set in Stone BT speaker" pairing name.
- 3. A tone will prompt and Bluetooth LED indicator(2) will tum solid BLUE ~ successfully paired.
- 4. Use your mobile device to cycle between songs and adjust the volume.
- 5. Speaker will automatically pair if the mobile device has been paired before.
- 6. Tum ON/OFF switch to the OFF position to tum off the device.

3. Aux Connection:

1. Connect an AUX cable(NOT INCLUDED) to the 3.5mm Aux input port(3) of the speaker and mobile device to play music directly.

SAFETY PRECAUTIONS

- 1. WARNING-When using this product, basic precautions should always be followed:
- 2. Read all the instructions before use.
- 3. Never store or use this product in temperatures below 32'F(O"C) or above 115'F(45'C).
- 4. Do not overcharge your Phone. The unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.
- 5. To reduce the risk of injury, close supervision is necessary when the product is used near children.
- 6. Do not expose the device to moisture.
- 7. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
- 8. Do not use the device if damaged or modified.
- 9. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- 10. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 104 °F may cause an explosion.
- 11. Ensure that qualified service professionals use only identical replacement parts to ensure product safety

FCC STATEMENT

Note: Thisequiprnmthasbeen te. tedand found simply with the !initsforaClass B di~tal device,p.irro.arttopart 15 of the FCC Rules. These limits are de~;ied to iro;; reason. reprotect on again. thannfulinterierence in aregdertialin.tallation Thiseqiprnmtgeneratesusesaulcanradiate radi of frequency, energy and, if nct in.talledandusedinaccorOO!lcewiththein. trixtiore,rraycause hannfulint reference to radio COmnmmications. However, their ism ~ee that interference will net occurinaparticulariret..lati m. Ifthisequipmert does cause harmful interference to radiate! evionreception,l.llichcan be detmni~byttrning theeqtiprnmtoff<11don,tbeuseris m: encouraged to try to correct their perform:everyone or !!Xlreof the fo llowif€mearores

- 1. Reorientorre!ocatetbereceivingartenm.
- 2. Increasethesei:ara,tionbetweentbeeqtipmentarrlreceiw:s:.
- 3. .ConrecttheequipmentintoanouU etonacirroitdifferertfromtJ-attomiich the rec'ver-scomected
- 4. .Conrultthe deal eroranexperim:edradicfTVtechnicianforhe!p
- 5. Toede.icehl.sbeenevallll.tedtomeet gema!RJexpos,xe reqtir=t. Thedevi ce can be us ed inp crtatiee;q:, rorecomttimwithrotrrnrictim

Documents / Resources



<u>DIGIVIEW 7197-49GY Stone Desktop Bluetooth Speaker</u> [pdf] Instruction Manual 7197-49BY, 719749BY, 2ADWN7197-49BY, 2ADWN719749BY, 7197-49GY, DSBT065A-C, Stone Desktop Bluetooth Speaker

Manuals+,