



Diivoo WT-08 Programmable Hose Timer 2 Outlet for Garden User Manual

[Home](#) » [Diivoo](#) » Diivoo WT-08 Programmable Hose Timer 2 Outlet for Garden User Manual 

Diivoo

WT-08 Programmable Hose Timer 2 Outlet for Garden User Manual


Thank You!

Need Help? : support@diivoosmart.com

Contents

- [1 Product Appearance](#)
- [2 Product Specifications](#)
- [3 Function Key Description](#)
- [4 Important Tips](#)
- [5 Operation Mode](#)
- [6 FAQ](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

Product Appearance



Packing List

1. Water Timer,*1
2. 1/2" inlet adapter" 1
3. Threaded connector*2
4. Thread Seal Tape"*1
5. Instruction*1

Product Specifications

Model: WT-08	Working Temperature	3°C-50°C (37.4°F-122°F)
	Waterproof	IP54
	Max Volumn	10gal/min (35L/min)
	Min/Max Working Pressure	0.5-8bar (7.25-116.03 psi)
	Power Supply	AA Alkaline Battery(1.5V)*2

Function Key Description

1. Turn the knob to set the function item.
2. After setting the parameter, it will be saved automatically after turning the knob.
3. Auto; OFF; Set Clock-set current time; Start Time-set start time; How Long-set working time; How Often-set interval time.
4. "+/-"keys to adjust time parameters.
5. "ZONE" key, switch channels.
6. "OK" key, long press for manual watering.
7. When time setting, "OK" key is to confirm and then jump to the next parameter setting.

Important Tips

1. Please do not use Carbon-zinc or rechargeable batteries.
2. Do not use your timer when the air temperature is below 3°C 37°F , the timers should be removed from the hose faucet and stored indoors to avoid potential frozen damage.
3. When replacing the power unit, please make sure that the water timer is dry.
4. Filter can trap dirt particles, please clean filter regularly and replace if worn to prevent blockage.

Operation Mode




1. Set Clock

Turn to Set clock to set up current time.(12H/24H)


2. Zone Switch

Press "ZONE" button to switch between Zone 1&2 while setting up the water timer.




3. Start Time

Turn to Start time to set the start time of watering scheduel for each zone




4. How Long

Turn to How long to set the duration of watering scheduel for each zone (1min~3h59min)



5. How Often

Turn to How often to set up watering interval for each zone.(1H~12H, 1D~7D)






6. Auto

Turn to Auto to initiate preset auto watering program




7. Off

Turn to Off to stop auto watering program.



8. Manual

Turn to "Auto" button, press and hold "OK" to set up Manual watering (1min~8h), first appear "Zone 1" when entering Manual mode, press "Zone" to switch to "zone 2", press again to select both Zones. Press and hold "OK" again to turn off manual watering and resume auto.



9. Rain Delay

Turn to “Auto” button, press and hold “+” to set up Rain delay (24H/48H/72H), Press and hold “+” again to turn off Rain delay.

FAQ

Q1: The LCD screen does not display anything?

A1: Make sure the batteries are properly placed in the battery box.

Q2: Water does not come out?

A2: Check if: 1. The programs are set up correctly. 2. The batteries are low. 3. The Faucet is turned off. 4. Rain delay is turned on.

Q3: The hose tap connection/outlet leaks? A3: Check if:

1. The O-ring is connected correctly to the hose tap. 2. The connection outlet or water pipe is broken. 3. The Sealer is missing or if it is tightly installed. 4. The faucet and water pipe has a different thread. If necessary, please use an appropriate adapter or PTFE tape.

Q4: Is it compatible with water bucket or drip system?

A4: No, because the water pressure of water bucket and drip system does not meet the pressure standard for water valve.

After-sales Service



<https://www.youtube.com/channel/UC-rdA7rXtm4tCvm3EdkGqEA>



<https://wa.me/qr/TUIVFNRVTOAPB1>

The timer have one year warranty, if you have any questions, please feel free to contact via.
support@diivoosmart.com If you need E-Manual, please scan the QR code or contact customer service.

**Manufacture: Zhuhai Tessian Power
Technology Co., Ltd.**



Company Name: YH Consulting Limited

Address: C/O YH Consulting Limited Office 147, Centurion House, London Road, Staines-upon-Thames, Surrey,
TW18 4AX



Company: E-CrossStu GmbH

Address: Mainzer Landstr.69,60329 Frankfurt am Main

