




Dimplex Optional Remote Control User Manual

[Home](#) » [Dimplex](#) » Dimplex Optional Remote Control User Manual 



Installation Guide Optional Remote Control



Model Numbers:

BFRC-KIT

BFRC-KIT-OP

IMPORTANT SAFETY INFORMATION: Always read this manual first before attempting to install it. For your safety, always comply with all warnings and safety instructions contained in this manual to prevent personal injury or property damage.

To view the full line of Dimplex products, please visit

www.dimplex.com

Always use a qualified technician or service agency to repair this fireplace.

! **NOTE:** Procedures and techniques that are considered important enough to emphasize.

! **CAUTION:** Procedures and techniques which, if not carefully followed, will result in damage to the equipment.

⚡ **WARNING:** Procedures and techniques which, if not carefully followed, will expose the user to the risk of fire, serious injury, or death.

Contents

- 1 Welcome & Congratulations
- 2 IMPORTANT INSTRUCTIONS
- 3 Remote Kit Installation
- 4 Operation
- 5 Maintenance
- 6 Warranty
- 7 Documents / Resources
- 8 Related Posts

i Welcome & Congratulations

Thank you and congratulations for choosing to purchase an electric fireplace from Dimplex, the world leader in electric fireplaces. Please carefully read and save these instructions.

! **CAUTION:** Read all instructions and warnings carefully before starting installation. Failure to follow these instructions may result in a possible electric shock, fire hazard and will void the warranty.



NO NEED TO RETURN TO THE STORE

Questions with operation or assembly? Require Parts Information? Product Under Manufacturer's Warranty?



Contact us at: www.dimplex.com/customer_support

For Troubleshooting and Technical Support



OR **Toll-Free 1-888-DIMPLEX** (1-888-346-7539) Monday to Friday 8:00 a.m. to 4:30 p.m. EST



IMPORTANT INSTRUCTIONS

1. Read all instructions before using this appliance.
2. Any repairs to this appliance should be carried out by a qualified service person.
3. Under no circumstances should this appliance be modified. Parts having to be removed for servicing must be replaced prior to operating this fireplace again
4. Do not use outdoors.
5. Use this appliance only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.


SAVE THESE INSTRUCTIONS




Remote Kit Installation

Installation Set-Up

1. Open steel curtain (remove glass doors if applicable).
2. Remove two screws on the log grate and remove the log grate. (FIGURE 1)




3. Pull the front edge of the plastic ember bed grate up and forward until the rear tab is released from the ledge located at the bottom of the mirror. (FIGURE 2)



NOTE: Log set fits tightly into the firebox, some force may be necessary to remove.


4. Locate and remove the two screws on the removable bracket. Remove the bracket.
(FIGURE 3)
5. Locate and depress the mounting tabs on the plug connector to remove the 'dummy plug'.
(FIGURE 3)



! NOTE: Keep the 'dummy plug in a safe place. You will need it if you decide to uninstall the remote control to operate the fireplace manually.]


Install Remote Control Receiver

1. Locate and insert the plug connector on the remote control bracket into the plug connector on the fireplace.
(FIGURE 4)
2. Place antenna under the remote bracket.



3. Locate and install the two screws on the remote control bracket.
4. Replace the log by inserting the front edge and pushing the back down until the rear tab snaps under the back ledge (FIGURE 2) and the logs are resting against the mirror.
5. Replace the log grate using two screws previously removed.

FIGURE 5



Manual Controls & Indicator Lights

Artistic Windows



Operation

Remote Control

The remote control has a range of approximately 50ft. (15.25m). It does not have to be pointed at the fireplace and can pass through most obstacles (including walls). It is supplied with one of 2, 187 independent frequencies, in the factory, to prevent interference with other units.

Remote Control Initialization/ Reprogramming

Follow these steps for remote control initialization and if required, re-initialization:




1. Ensure that power is supplied through the main service panel.
2. Access the manual controls, (remove the glass doors if applicable) pull the right-hand steel curtain to the outside of the unit. (FIGURE 5)
3. Locate manual controls.
4. Move the 3-way switch to "Remote".
5. Activate the main power switch, the red Level 1 Indicator Light will flash . (Figure 6-D)
6. Press and hold the On button on the manual controls (Figure 6-A) for five (5) seconds. The Level 1 Indicator Light  (Figure 6-D) will then flash for 10 seconds.
7. **Within** 10 seconds press the ON button located on the remote control transmitter. (Figure 7) This will synchronize the remote control transmitter and receiver.

Figure 6



Remote Control Usage

The remote control operation can be adjusted, depending on the season and desired effects, by toggling the main mode selector switch built into the fireplace. The position of the switch will dictate the available functions that the remote transmitter will cycle through.

A. On Button

Pressing this button toggles sequentially through the three levels of the fireplace.

- Mode Selector Set at "O": Only Flame Effect at all 3 levels.
- Mode Selector Set at "–": Pressing once activates Level 1 – flame effect only, two and three times activates Level 2 – flame effect and Fan.
- Mode Selector Set at "≡": Pressing once activates Level 1 – flame effect only, twice activates Level 2 – flame effect and Fan, three times activates Level 3 – flame effect, Fan and heat.

B. Off Button




Pressing this button at any time will shut the unit off.


C. Manual Selection Switch

Switches the operation of the fireplace between the different modes of the fireplace:

- OFF (center): Makes the unit inoperable.
- MANUAL (top): All functions of the fireplace are controlled by the On and Off buttons as described above (A, B).
- REMOTE (bottom): All functions of the fireplace are controlled by the Remote Control.

D. LED Indicators

Depicts which of the three (3) levels the fireplace is currently operating at Level 1 – , Level 2 –  or Level 3 – 



Battery Replacement

(Figure 7)

To replace the battery:

- Slide battery cover opens on the handheld transmitter.
- Correctly install one (1) 12 Volt (A23) battery in the battery holder.
- Close the battery cover.



Warranty

All Dimplex accessories are warranted against defects in workmanship and materials for two years from the date of sale. This warranty does not apply to damage from an accident, misuse, or alteration, nor where the connected voltage is more than 5% above the nameplate voltage, nor to equipment improperly installed or wired or maintained in violation of the instruction sheet. This limited warranty applies only to purchases made in any province of Canada except for Yukon Territory, Nunavut, or Northwest Territories or in any of the 50 States of the USA (and the District of Columbia) except for Hawaii and Alaska. This limited warranty applies to the original purchaser of the product only and is not transferable. No other written or oral warranty applies. No employee, agent, dealer, or other person is authorized to give any warranties on behalf of Dimplex.

The customer shall be responsible for all costs incurred in the removal or reinstallation and shipping of the product for repairs. Within the limitations of this warranty, inoperative units shall be returned to the nearest Dimplex authorized service center, and we shall repair or replace, at our option, at no charge to you with return freight paid to be Dimplex. It is agreed that such repair or replacement is the exclusive remedy available from Dimplex and that DIMPLEX IS NOT RESPONSIBLE FOR DAMAGES OF ANY KIND, INCLUDING INCIDENTAL AND CONSEQUENTIAL DAMAGE. Some states do not allow the exclusion or limitation of consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



www.dimplex.com

Dimplex North America Limited


1367 Industrial Road

Cambridge ON

Canada N3H 4W3

© 2017 Dimplex North America Limited

Documents / Resources

 <p>3CDimplex Installation Guide Optional Remote Control Model Numbers: BFRC-KIT BFRC-KIT-OP</p> <p><small>IMPORTANT SAFETY INFORMATION: Always read the manual that comes with the product. For your safety, please read the manual before using the product. The manual contains important information that could prevent injury or property damage. To view the full text of the Dimplex products, please visit www.dimplex.com</small></p>	<p>Dimplex Optional Remote Control [pdf] User Manual Dimplex, Optional, Remote Control, BFRC-KIT, BFRC-KIT-OP</p>
---	---