



DINAN D100-0936 Performance Spring Set Instructions

[Home](#) » [DINAN](#) » DINAN D100-0936 Performance Spring Set Instructions 

DINAN D100-0936 Performance Spring Set Instructions



Contents

[1 INSTALLATION NOTES](#)

[2 Documents /
Resources](#)

[3 Related Posts](#)

INSTALLATION NOTES

PLEASE READ BEFORE BEGINNING INSTALLATION

The front & rear springs look very similar to each other. Please refer to the part number printed on each spring to determine the correct installation location:

- D100-0860 = Front Spring
- D100-0862 = Rear Spring

For best results, we recommend installation of the companion handling kit, p/n D193- 0121.

Alignment:

- An alignment is required after installation.
- All Dinan suspension alignments are done with full fuel tanks and no weight inside the vehicle.
- Specifications are as follows:


FRONT	Setting	Tolerance
Camber	-1.8°	± 0.42°
Caster	8.0°	± 0.5°
Total Toe	0.17°	± 0.03°
REAR		
Camber	-1.5°	± 0.08°
Total Toe	0.23°	± 0.03°

If you encounter any difficulties during the installation, or if these instructions are not clear to you, please call Dinan's Technical Support Staff @ (800) 341-5480.

Happy Motoring!



Documents / Resources

	DINAN D100-0936 Performance Spring Set [pdf] Instructions D100-0936 Performance Spring Set, D100-0936, Performance Spring Set, Spring Set
---	--