

# Divoom SIGNAL Pixoo Backpack Signal Remote Control User Manual

[Home](#) » [Divoom](#) » Divoom SIGNAL Pixoo Backpack Signal Remote Control User Manual 

## Contents

- [1 Divoom SIGNAL Pixoo Backpack Signal Remote Control](#)
- [2 introduction](#)
- [3 Product specification](#)
- [4 FAQ](#)
- [5 WARRANTY INFORMATION](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



## **Divoom SIGNAL Pixoo Backpack Signal Remote Control**



### **introduction**

#### **Pixar Backpack Signal Control User Guide Left Left Arrow**

- Right Right Arrow
- 3 Channel Button
- Press: Change Channels
- Hold: Change Light Effects
- Hold For 5 Seconds: Enter Pairing Mode
- Power Power Button
- Press: Displays custom images
- Hold: Power On/Off Signal Control
- 6 Indicator Light

### **HOW TO PAIR THE SIGNAL CONTROL?**

1. Connect the backpack with a Power Bank, then power on the remote control.
2. In the Divoom APP, pair the Pixoo backpack, then go to Settings> Devices.
3. Select Pair Signal remote control
4. Hold the Ch button for 5 seconds. After the LED flash, the remote is in pairing mode.

5. On the Divoom APP, tap the 'Start pairing'.
6. The signal remote control would be paired after a few seconds.

## **HOW TO INSTALL THE SIGNAL CONTROL (W/Bike Mount)?**

1. Make sure the Signal Control is charged and paired
2. Rotate clockwise to install the remote control on the bike mount.
3. Install the bike mount on to the handle bar

## **Product specification**

- Product size (mm):  
51.26L61.78W\*71.63H
- Product weight:  
55g
- Duration of use:  
28hrs
- Battery capacity:  
95mAh
- Battery voltage:  
3.7V
- Charging voltage:  
5V1A
- Transmission distance  
5m
- Bluetooth version:  
5.0

## **FAQ**

1. What is the battery life for the Signal Control?  
For average 2hrs bike riding per day, the remote control can provide up to 14 days battery life. You can press its power button, and its battery level will be show on the backpack Screen.
2. Can I use the Signal Control in the rain?  
Yes, the Signal Control is splash proof, so you can use it even in the heavy rain. However, do not drop Signal Control in the water, and do not use the Signal Control in the rain while charging.
3. I am having problem to pair with my Signal Control.
  1. Make sure the Divoom APP is connected with the Backpack.
  2. Make sure the Signal Control remote is ON, and then hold the OCh button for 5 seconds.
  3. After the remote is in the pairing mode, then press the 'Start pairing' on the APP.
  4. If step b &c order is reversed, the remote may fail to pair.
  5. If none of the above method works, please try restarting both devices, and repeat the remote control pairing steps.
4. Do I need to use the APP to pair the Signal Control every single time?

No, after the first pairing, the signal remote control automatically pair with the backpack.  
Just power ON both backpack and remote control, they will be paired within 15 seconds.

5. What is the connection range for the Signal Control?

Around 5 meters.

6. What are the LED means?

If it's flashing a single LED, it means it's waiting to connect with the backpack

If it has the solid LED, it means the Signal Control is paired with the backpack.

IF it has all three LED flashing, it means the signal remote control is in the pairing mode.

## WARRANTY INFORMATION


1. If you believe your product is defective within the warranty period, please check with the store where it was initially purchased.
2. If within 12 (24 if required by local law) months of purchase this device or any part thereof is proven to be defective by reason of faulty workmanship or defects in materials, we will at our option repair or replace the same free of charge of labor or materials at its current condition.
3. The sales invoice or receipt with the date and source of purchase must be presented together with the defective unit.
4. The warranty does not cover product failures which have been caused by use of accessories other peripheral devices which are not Divoom branded original accessories..
5. The warranty does not cover product failures caused by: modification, repaired, and disassembling by any person who is not authorized by the manufacture.
6. The warranty is nontransferable.
7. The warranty does not cover any damage caused by misuse, drop, hit or negligence.
8. The customer is responsible for the return shipping charges.
9. This warranty only covers the electrical components of the product.

Please dispose the used battery properly following local law. Do NOT incinerate.

Removal of the rechargeable lithium-ion battery in this product should be conducted only by a qualified professional.

This product is covered by a limited warranty from Divoom. For complete warranty details, visit the website [www DivOOM GO](http://www.DivOOM.GO)

## Documents / Resources

	<a href="#">Divoom SIGNAL Pixoo Backpack Signal Remote Control [pdf] User Manual</a> SIGNAL Pixoo Backpack Signal Remote Control, Pixoo Backpack Signal Remote Control, Signal Remote Control, Remote Control
---	--