

DIY MORE AT2-PCB Universal Timer Trigger Cycle Timer Delay Switch Circuit Board Instructions

Home » DIY MORE » DIY MORE AT2-PCB Universal Timer Trigger Cycle Timer Delay Switch Circuit Board Instructions

DIY MORE AT2-PCB Universal Timer Trigger Cycle Timer Delay Switch Circuit Board Instructions




Contents

- 1 Specifications
- 2 Overview
- 3 Wiring options
- 4 Select A Time Function -
- **5 Terminology**
- 6 Programming
- 7 Time Intervals
- 8 Operation from Power
- Up
- 9 Documents / Resources
- 10 Related Posts


Specifications

Input Voltage 5 – 24VDC Trigger Voltage 5 – 24VDC Relay Contacts 5 – 30VDC @ 5A Standby Current 20mA Operating Current 50mA
Time Increments 0.1 sec to 16.5 hours
Dimensions 63 x 37 x 20mm
Operating Temp -20 to 60 Degrees
Time Functions 9 Selectable Modes
Mounting Holes 3mm

Overview





Wiring options





Select A Time Function -


Example PL1, P1.2 etc

















Warning

<15VDC – The relay on this product is rated for continuous use with a power input up to 15VDC.

>24VDC – The relay on this product is rated for up to 5 minutes of continuous use with a 10% duty cycle with a power input up to 24VDC.

Terminology

Enter Program Mode: Press Et hold the SET button for 2 seconds, then release.

EXIT Program Mode: Press 8 hold the SET button for 2 seconds, then release.

OP = Relay ON Time. **CL** = Relay OFF Time.

LOP = Loop (number of operation cycles per trigger).

Programming

- First choose the time mode you wish to use from the tables on the previous page. I.e. P-2, P3.2 etc.
- Now enter program mode by pressing and holding the **SET** button for 2 seconds, then releasing. The current time mode will display (i.e. P1.1) to indicate that you are in program mode.
- Next use the **UP** & **DOWN** buttons to scroll to the time mode you wish to use, then press **SET** to confirm.
- Now set the values for **OP**, **CL** or **LOP** by using the **UP** & **DOWN** buttons, followed by **SET** to save.

Note: Certain time modes will only include OP and some can include OP, CL & LOP as shown in the tables on the previos page.

Time Intervals


When setting the OP S/or CL value you can choose the period to be either milliseconds, seconds or minutes.
 You can change between these time periods with each press of the STOP button followed by the SET button to save.

See examples below:

Example = 5 Milliseconds Example = 5 Seconds



Example = 5 Minutes



- LOP (cycles) is used for time modes P3.1 & P3.2 and can be set to a number of cycles or — for infinite cycles.
- Once the required **OP, CL, LOP** & time value are set, return the module to operating mode by pressing & holding the SET button for 2 seconds then releasing. The module will flash the current time mode before returning to operating mode.

Operation from Power Up

• After every power up the timer will return to the last programmed time mode. The timer will then wait for a trigger to begin operation. Alternatively time mode P3.2 will start operation automatically on power up. (see previous page for the complete table of time modes).





Supplied by AAP Ltd 3443 Rosedale Rd, Albany 0632, Auckland, NZ



Documents / Resources



<u>DIY MORE AT2-PCB Universal Timer Trigger Cycle Timer Delay Switch Circuit Board</u> [pdf] Instructions

AT2-PCB, Universal Timer Trigger Cycle Timer Delay Switch Circuit Board, AT2-PCB Universal Timer Trigger Cycle Timer Delay Switch Circuit Board

Manuals+,