dji FC40 Phantom with its Own Smart Camera User Guide

Contents

**dji FC40 Phantom with its Own Smart Camera**



INSTALLATION

INSTALL DJI FC40 TO AIRCRAFT

**WARNING:** 4 Use the mount kit in the PHANTOM package.

INSERT THE MICDO.SD CARD

INSTALL THE CAMERA

TURN ON THE CAMERA

INSTALL DJI FC40 APP

Available on the App Store

Get it on Google play

Scan The QR Code To
Download iOS/Andriod App

CONNECT TO THE CAMERA

SETTINGS	WI-FI	
WI-FI		I ⬤
Choose a Network ...		
DJI F AP1		🔒 📶 ❯
✓ DJI FC40-000001		🔒 📶 ❯

DJI FC10 FEATURE

SPERKER
扬声器

POWER BUTTON
电源开关

LED STATUS
指示灯

RECORD BUTTON
录像开关

MIC
麦克风

MICRO USB PORT
Micro-USB接口

MICRO SD CARD SLOT
Micro-SD卡插槽

GUIDE FOR CAMERA HOTKEY & LED

CAMERA HOTKEY

- **Power Off:** Press the power button for 5 seconds.
- **Recording:** Press the record button for

CONDITIONS	状态	STATUS INDICATOR	状态指示灯	SOUND	声音
Recording	录像	🟢 🟢 🟢 🟢		One Time	1次
Charging	充电	🔴 🔴 🔴 🔴			
Low Power	低电压	🔴🔴🔴🔴🔴🔴		Five Times	5次
Power Off	关闭电源			Two Times	2次
Auto Power Off (5 Mins Idle)	5分钟闲置 关闭电源	🔴 🔴 🔴 🔴		Two Times	2次
WI-FI Connecting	WI-FI链接	🟢🟢🟢🟢🟢🟢			
Memory Full Micro-SD Card Error	内存已满或者 内存卡错误	🔴 🔴 🔴 🔴		Three Times	3次

LEARN MORE: **WWW.DJI.COM**

Documents / Resources

	dji FC40 Phantom with its Own Smart Camera [pdf] User Guide FC40 Phantom with its Own Smart Camera, FC40, Phantom with its Own Smart Camera, Own Smart Camera, Smart Camera, Camera

References

- ᴹᴴ **Search - Manual-Hub.com**