

dji Mini 4 Pro More Combo Plus Drone and RC 2 Remote Control User Guide

dji Mini 4 Pro More Combo Plus Drone and RC 2 Remote Control User Guide

<https://s.dji.com/guide66>

Charge to Activate the Battery

Charge to activate the Intelligent Flight Battery before using for the first time.

Check battery level: press once.
Power on/off: press, then press and hold.

<https://www.dji.com/mini-4-pro/downloads>

Contact DJI SUPPORT

DJI is a trademark of DJI.

Copyright © 2023 DJI All Rights Reserved

- Contents
- [1 Documents / Resources](#)
- [2 Related Posts](#)

Documents / Resources

	dji Mini 4 Pro More Combo Plus Drone and RC 2 Remote Control [pdf] User Guide Mini 4 Pro More Combo Plus Drone and RC 2 Remote Control, Mini 4, Pro More Combo Plus Drone and RC 2 Remote Control, Drone and RC 2 Remote Control, Remote Control, Control
---	--